


Smart choice for power™

xantrex™



Freedom SW 3012 shown.

Freedom SW Sine Wave Inverter/Chargers

Owner's Guide

Model Numbers

815-3012, 815-3024
815-2012, 815-2024

xanbus™
E N A B L E D

Copyright © 2014-2019 Xantrex LLC. All Rights Reserved. All trademarks are owned by Xantrex LLC or its affiliated companies.

Exclusion for Documentation

UNLESS SPECIFICALLY AGREED TO IN WRITING, SELLER

(A) MAKES NO WARRANTY AS TO THE ACCURACY, SUFFICIENCY OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN ITS MANUALS OR OTHER DOCUMENTATION;

(B) ASSUMES NO RESPONSIBILITY OR LIABILITY FOR LOSSES, DAMAGES, COSTS OR EXPENSES, WHETHER SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL OR INCIDENTAL, WHICH MIGHT ARISE OUT OF THE USE OF SUCH INFORMATION. THE USE OF ANY SUCH INFORMATION WILL BE ENTIRELY AT THE USER'S RISK; AND

(C) REMINDS YOU THAT IF THIS MANUAL IS IN ANY LANGUAGE OTHER THAN ENGLISH, ALTHOUGH STEPS HAVE BEEN TAKEN TO MAINTAIN THE ACCURACY OF THE TRANSLATION, THE ACCURACY CANNOT BE GUARANTEED. APPROVED CONTENT IS CONTAINED WITH THE ENGLISH LANGUAGE VERSION WHICH IS POSTED AT WWW.XANTREX.COM.

Document Part Number

97-0019-01-01

Date and Revision

Aug 2019 Rev H

Product Numbers

815-2012 (Freedom SW 2012), 815-2024 (Freedom SW 2024)

815-3012 (Freedom SW 3012), 815-3024 (Freedom SW 3024)

Contact Information

Telephone: 1 800 670 0707 (toll free North America)
1 408 987 6030 (direct)

Web: www.xantrex.com

Information About Your System

As soon as you open your product, record the following information and be sure to keep your proof of purchase.

Serial Number _____

Product Number _____

Purchased From _____

Purchase Date _____

To view, download, or print the latest revision, visit the website shown under Contact Information.

About This Guide

Purpose

The purpose of this Owner's Guide is to provide explanations and procedures for operating, troubleshooting, and maintaining the Freedom SW Inverter/Charger.

Scope

The Guide provides safety and operating guidelines as well as information on configuring the inverter/charger. It also provides information about troubleshooting the unit. It does not provide details about particular brands of batteries. You need to consult individual battery manufacturers for this information.

Audience

The Guide is intended for users and operators of the Freedom SW Inverter/Charger.

Related Information

You can find more information about Xantrex-branded products and services at www.xantrex.com.

For information on product installation, please refer to the *Freedom SW Installation Guide* (Document Part Number: 97-0020-01-01).

NOTE: The Installation Guide is primarily intended for qualified personnel who need to install and configure the Freedom SW Inverter/Charger.

Qualified personnel have training, knowledge, and experience in:

- Installing electrical equipment and PV power systems (up to 1000 volts).
- Applying all applicable installation codes.
- Analyzing and reducing the hazards involved in performing electrical work.
- Selecting and using Personal Protective Equipment (PPE).

Important Safety Instructions

IMPORTANT: READ AND SAVE THIS OWNER'S GUIDE FOR FUTURE REFERENCE.

This chapter contains important safety and installation instructions for the Freedom SW Inverter/Charger (Freedom SW). Each time, before using the Freedom SW, READ ALL instructions and cautionary markings on or provided with the inverter/charger, the batteries, and all appropriate sections of this guide.

NOTE: The Freedom SW contains no user-serviceable parts.

The following special messages may appear throughout this bulletin or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, can result in death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation, which, if not avoided, can result in moderate or minor injury.

NOTICE

NOTICE indicates a potentially hazardous situation, which, if not avoided, can result in equipment damage.

IMPORTANT: These notes describe things which are important for you to know, however, they are not as serious as a caution or warning.

Safety Information

DANGER

ELECTRICAL SHOCK HAZARD

- Do not expose the Freedom SW to rain, snow, spray, or bilge water. This inverter/charger is designed for marine applications only when additional drip protection is installed in certain orientations. See the installation guide for information.
- Do not operate the inverter/charger if it has received a sharp blow, been dropped, has cracks or openings in the enclosure including if the AC terminal cover has been lost, damaged, or will not close, or otherwise damaged in any other way.
- Do not disassemble the inverter/charger. Internal capacitors remain charged after all power is disconnected.
- Disconnect both AC and DC power from the inverter/charger before attempting any maintenance or cleaning or working on any circuits connected to the inverter/charger. The **INVERTER ENABLE** button on the front panel does not function like a power switch that energizes or de-energizes the unit arbitrarily. When AC and DC power sources are connected and present, the unit is always energized.
- Do not operate the inverter/charger with damaged or substandard wiring. Make sure that all wiring is in good condition and is not undersized.

Failure to follow these instructions will result in death or serious injury.

DANGER

FIRE AND BURN HAZARD

- Do not cover or obstruct the air intake vent openings and/or install in a zero-clearance compartment.
- Do not use transformerless battery chargers in conjunction with the inverter/charger due to overheating.

Failure to follow these instructions will result in death or serious injury.

DANGER

EXPLOSION HAZARD

- Charge only properly rated (such as 12 V) lead-acid (GEL, AGM, Flooded, or lead-calcium) rechargeable batteries because other battery types may explode.
- Do not work in the vicinity of lead-acid batteries. Batteries generate explosive gases during normal operation. See note #1.
- Do not install and/or operate in compartments containing flammable materials or in locations that require ignition-protected equipment. See notes #2 and #3.
- When using Lithium-Ion batteries, ensure that the battery pack being used includes a certified Battery Management System (BMS) with safety controls.

Failure to follow these instructions will result in death or serious injury.

NOTES:

1. Follow these instructions and those published by the battery manufacturer and the manufacturer of any equipment you intend to use in the vicinity of the battery. Review cautionary markings on these products and on the engine.
2. This inverter/charger contains components which tend to produce arcs or sparks.
3. Locations include any space containing gasoline-powered machinery, fuel tanks, as well as joints, fittings, or other connections between components of the fuel system.

Precautions When Working With Batteries

WARNING

BURN FROM HIGH SHORT-CIRCUIT CURRENT, FIRE AND EXPLOSION FROM VENTED GASES HAZARDS

- Always wear proper, non-absorbent gloves, complete eye protection, and clothing protection. Avoid touching your eyes and wiping your forehead while working near batteries. See note #4.
- Remove all personal metal items, like rings, bracelets, and watches when working with batteries. See notes #5 and #6 below.
- Never smoke or allow a spark or flame near the engine or batteries.
- Never charge a frozen battery.

Failure to follow these instructions can result in death or serious injury.

NOTES:

1. Mount and place the Freedom SW Inverter/Charger unit away from batteries in a well ventilated compartment.

2. Always have someone within range of your voice or close enough to come to your aid when you work near a lead-acid battery.
3. Always have plenty of fresh water and soap nearby in case battery acid contacts skin, clothing, or eyes.
4. If battery acid contacts skin or clothing, wash immediately with soap and water. If acid enters your eye, immediately flood it with running cold water for at least twenty minutes and get medical attention immediately.
5. Use extra caution to reduce the risk of dropping a metal tool on the battery. It could spark or short circuit the battery or other electrical parts and could cause an explosion.
6. Batteries can produce a short circuit current high enough to weld a ring or metal bracelet or the like to the battery terminal, causing a severe burn.
7. When removing a battery, always remove the negative terminal from the battery first for systems with grounded negative. If it is grounded positive, remove the positive terminal first. Make sure all loads connected to the battery and all accessories are off so you don't cause an arc.

Precautions When Preparing to Charge

WARNING

EXPOSURE TO CHEMICALS AND GASES HAZARD

- Make sure the area around the battery is well ventilated.
- Make sure the voltage of the batteries matches the output voltage of the inverter/charger.
- Be careful to keep corrosion from coming into contact with your eyes and skin when cleaning battery terminals.

Failure to follow these instructions can result in death or serious injury.

NOTES:

- Study and follow all of the battery manufacturer's specific precautions, such as removing or not removing cell caps while charging, whether equalization is acceptable for your battery, and recommended rates of charge.
- For flooded non-sealed batteries, add distilled water in each cell until battery acid reaches the level specified by the battery manufacturer. This helps to purge excessive gas from cells. Do not overfill. For a battery without removable cell caps, carefully follow manufacturer's instructions.

Precautions When Placing the Inverter/Charger

NOTICE

RISK OF DAMAGE TO THE INVERTER/CHARGER

- Never allow battery acid to drip on the inverter/charger when reading gravity, or filling battery.
- Never place the Freedom SW Inverter/Charger unit directly above batteries; gases from a battery will corrode and damage the inverter/charger.
- Do not place a battery on top of the inverter/charger.

Failure to follow these instructions can damage the unit and/or damage other equipment.

Regulatory

The Freedom SW Inverter/Charger is certified to appropriate US and Canadian standards. For more information see “Regulatory Approvals” on the Specifications section in the Owner’s Guide.

The Freedom SW Inverter/Charger is intended to be used for mobile or commercial applications. This inverter/charger is designed for marine applications only when additional drip protection is installed in certain orientations.

It is not intended for other applications as it may not comply with the additional safety code requirements needed for those other applications. See “Limitations On Use” below.

WARNING

LIMITATIONS ON USE

Do not use in connection with life support systems or other medical equipment or devices.

Failure to follow these instructions can result in death or serious injury.

FCC Information to the User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Unauthorized changes or modifications to the equipment could void the user’s authority to operate the equipment.

End of Life Disposal

The Freedom SW is designed with environmental awareness and sustainability in mind. At the end of its useful life, the Freedom SW can be decommissioned and disassembled. Components which can be recycled must be recycled and those that cannot be recycled must be disposed of according to local, regional, or national environmental regulations.

Many of the electrical components used in the Freedom SW are made of recyclable material like steel, copper, aluminum, and other alloys. These materials can be auctioned off to traditional scrap metal recycling companies who resell reusable scraps.

Electronic equipment such as the circuit boards, connectors, and fuses can be broken down and recycled by specialized recycling companies whose goal is to avoid having these components end up in the landfill.

For more information on disposal, contact Xantrex.

Contents

| | |
|---|-----|
| Important Safety Instructions | iii |
| Introduction | 1 |
| Materials List | 2 |
| Key Features | 3 |
| Key Features Explained | 4 |
| Stacking | 5 |
| Stack Charging | 5 |
| Generator Assist | 6 |
| Basic Protection Features | 6 |
| System Components | 7 |
| Xanbus System | 7 |
| Xanbus-enabled Products and Accessories | 9 |
| Freedom SW Inverter/Charger Mechanical Features | 10 |
| Freedom SW Front and Side Panels | 11 |
| Freedom SW AC and DC Side Panels | 14 |
| Freedom SW Supplied Accessories | 15 |
| Freedom Inverter/Charger Operation | 17 |
| Start Up Behavior | 17 |
| Inverter Operation Using the Front Panel | 18 |
| Operating Limits for Inverter Operation | 20 |
| Operating Limits for Charger Operation | 21 |

| | |
|--|----|
| Operating the Freedom SW with the SCP | 23 |
| Using the Xanbus SCP | 24 |
| System Control Panel | 24 |
| SCP Navigation | 27 |
| Startup Screen | 27 |
| Viewing the SCP Home Screens | 27 |
| Soft Key Navigation | 29 |
| Viewing the Firmware Revision Number | 31 |
| Setting the Time and Date | 32 |
| Using the STBY/ON Fault Clear Button | 32 |
| Reading the System Status Screen | 33 |
| Reading the Freedom SW Device Setup Screen | 35 |
| Configuring the Freedom SW using the SCP | 39 |
| System Menu Map | 39 |
| Viewing the System Status Screen | 40 |
| Viewing the Select Device Menu | 40 |
| Selecting the Freedom SW from the Select Device Menu | 41 |
| Changing Configurable Settings From The Device Setup Menu Screen | 42 |
| Using Search Mode | 45 |
| Equalization Procedure | 47 |
| Changing Freedom SW Basic Settings | 48 |
| Changing Freedom SW Advanced Settings | 53 |
| Inverter Settings Menu | 57 |
| Using the Low Battery Cut Out and LBCO Delay Settings | 58 |
| Charger Settings Menu | 60 |
| Battery Charger Functions | 62 |
| Custom Battery Settings Menu | 63 |

| | |
|--|-----|
| ACIn Settings | 65 |
| Gen Support | 67 |
| Stacking Configuration Menu | 69 |
| Setting the Device Name | 71 |
| Setting the Device Number | 72 |
| Cascading | 73 |
| Resetting the Freedom SW to Default Settings | 74 |
| Using the Advanced Features | 75 |
| Battery Charging Reference | 77 |
| Battery Types | 77 |
| Charge Algorithm Stages | 78 |
| Three-Stage charging | 78 |
| Two-Stage Charging Process | 82 |
| Equalize Charging | 84 |
| Troubleshooting | 87 |
| General Troubleshooting Guidelines | 87 |
| Inverter Applications | 88 |
| Resistive Loads | 88 |
| Motor Loads | 88 |
| Problem Loads | 88 |
| Troubleshooting the Freedom SW via the SCP | 90 |
| Detected Fault Types | 90 |
| Detected Warning Types | 92 |
| Specifications | 105 |

Introduction

Congratulations on your purchase of the Freedom SW Inverter/Charger (Freedom SW). The Freedom SW has been designed to give you premium power, ease of use, and outstanding reliability.

Please read this chapter to familiarize yourself with the main performance and protection features of the Freedom SW.

Materials List

The Freedom SW ships with the following items:

- One Freedom SW unit
- Owner's and Installation Guides
- Battery Temperature Sensor (BTS)
- DC terminal covers (one red, one black) with two sets of #6-32 screws
- Two Xanbus network terminators
- Two sets of 5/16"-18 nuts and washers for the DC terminals

NOTE: If any of the items are missing, contact customer service or any authorized Xantrex dealer for replacement. See "About This Guide" on page ii.

IMPORTANT: Keep the carton and packing material in case you need to return the Freedom SW for servicing.




Figure 1 Materials List

Key Features

The Freedom SW Inverter/Charger is a true sine wave inverter/charger that can be used for mobile, marine and commercial applications. The Freedom SW Inverter/Chargers are designed to operate with a wide variety of generators and are capable of operating in parallel with a generator for short durations to assist with starting large loads. The Freedom SW is a convenient combination of an inverter, multistage battery charger, and transfer switch in one electronic device.

- As an inverter, the Freedom SW provides true sine wave power for your microwave, entertainment system, computer, and other loads. This power is identical to the AC source provided from the utility grid (power company).
- Some of the benefits of true sine wave power include consistent cooking in your microwave, handling of sensitive loads such as your TV set, dimmer switches, and appliances with speed controls.
- Highly versatile platform capable of series stacking for 120/240V line configurations and parallel stacking to increase power levels.
- High efficiency true sine wave output to power sensitive electrical and electronic equipment.

- Surge capacity to start difficult loads like refrigerators or A/C compressors.
- Power factor-corrected (PFC) input minimizes AC input current required for charging, increasing AC pass-through capacity.
- As a charger, it has high output, multistage charging capability minimizing charging time.
- Capable of operating from 50 Hz and 60 Hz power source by extending AC qualification frequency range. See “ACIn Settings” on page 65.

IMPORTANT: Dual Line models require only the Line 1 Input to be energized in order to qualify AC. Line 2 Input does not have to be powered in a single phase system.

- Temperature-controlled, variable-speed internal cooling fans. The fans turn on when the internal temperature reaches 45 °C (113 °F) and reaches maximum speed at 70 °C (158 °F). The fan turns off when the internal temperature falls to 40 °C (104 °F).
- Designed with serviceability in mind via Authorized Service Centers (ASC).
- The Freedom SW Inverter/Charger is also Xanbus-enabled which allows network compatibility and communication with other Xanbus-enabled devices. See more information under “System Components” on page 7.

Key Features Explained

Built-in Charge Formulas For the unit to perform at the highest level, the batteries must be charged correctly. The Freedom SW has optimized algorithms for flooded, gel, and AGM batteries.

Battery Temperature Sensor Since battery temperature is a key factor in correct charging, the charging formula must be adjusted (automatically and in real time) according to the actual battery temperature to ensure that batteries are fully charged, but not overcharged. For this reason, a battery temperature sensor is included with your Freedom SW and has temperature compensated the charge formula.

Manual Equalization Over a period of time, the cells in a flooded battery can develop uneven chemical states. This can result in a weak (undercharged) cell which, in turn, can reduce the overall capacity of the battery. To improve the life and performance of a non-sealed, flooded battery, the Freedom SW's multistage charging cycle includes a manual equalize mode that can be used, if recommended by the battery manufacturer.

Dead Battery Charging Another feature that the Freedom SW includes is dead battery charging. The Freedom SW—unlike many chargers—has the ability to recharge batteries

even if the battery voltage is very low (5 volts for Freedom SW 2012 / 3012 units and 12 volts for Freedom SW 2024 / 3024 units).

Load Management The Freedom SW has a built-in transfer relay that connects your inverter output or AC input from the utility grid or generator to your loads. Because the usual AC power sources such as campground outlets or small generators often have limited current availability, having the capability to manage your AC loads is extremely valuable. The Freedom SW provides a number of features to facilitate this:

- The charger is power factor corrected to use AC current as efficiently as possible. Minimizing the AC current used by the charger means more current is available for your AC loads.
- Freedom SW has a power share feature which prioritizes your AC loads by reducing the charge current in an attempt to limit the total input current to less than the breaker setting.

Occasionally, AC input sources have low voltage. To avoid loading these weak sources any further, the charger automatically reduces its AC current draw as the AC voltage approaches the minimum acceptable level.

Stacking

Supports stacking of two inverterchargers to increase capacity. This also requires the installer to select a Master and Slave in order for the inverters to stack. Two configurations of stacking are supported: Parallel stacking and Series stacking.

Parallel Stacking Parallel stacking allows two inverterchargers to operate in parallel thereby doubling the capacity in inverter mode. The two inverters communicate over the network and intelligently share the load and to balance the load between the two units. The Master Freedom SW broadcasts pulses on the Xanbus network to synchronize operation between the other paralleled unit. When AC loads are present, both units produce power, effectively sharing the load. When Search mode is enabled, only the Master unit produces the AC output.

Series Stacking Two units can be configured to generate 120/240 Split-phase power for load configurations that require both 120 and 240 volts. In this configuration, the AC source must be split-phase as well.

Stack Charging

Two Freedom SWs synchronize charging stages to ensure efficient charging of the battery bank. When a single unit transitions from bulk to absorption so do all other units. In absorption, all units must complete the absorption stage before transitioning to the next stage. Note that units do not load share when charging except during the bulk stage. The Freedom SWs stop sharing charge current just before completing the bulk stage. The units do not share charge current during the absorption and float stages.

Each unit charges batteries based on the Max Charge Rate setting and active internal (temperature-based) deratings.

If equalization is enabled on one or more devices capable of equalization charging, only those devices perform an equalize cycle after absorption. Other devices transition to float (if three-stage charging is selected) or transition to AC pass-through (if two-stage charging is selected).

Generator Assist

The Freedom SW Series of inverter/chargers can operate in tandem with a generator (or shore power) to temporarily assist power loads with large start-up demands such as air conditioners, water pumps etc. A Xanbus AGS is not required for this feature to work when shore power is present to assist the Freedom SW but the AGS is needed if a generator were to be used in assisting the Freedom SW.

When the **Gen Support** mode is enabled and the generator's or shore power's current capacity defined (in amps), the inverter will come on-line and assist the generator or shore power with starting and operating the load (drawing power from the battery). The battery bank must be well charged in order for the inverter to engage this mode. For more details, see "Gen Support" on page 67.

Basic Protection Features

The Freedom SW has the following protection features:

- Over temperature shutdown for critical components such as the transformer and the power board
- Battery temperature sensor (BTS) failure/battery temperature out-of-range fault protection
- DC output over voltage protection during charge mode
- AC transfer relay failure detection
- AC output overload and short circuit protection during invert mode
- AC backfeed¹ protection
- Short circuit protection for the BTS and communication connector ports including protection from incorrectly inserting the remote panel communication cable plug into the BTS port and vice versa

The Battery Temperature Sensor (BTS) provides these protection features:

- Battery over temperature charging protection preventing battery charging at 60 °C (140 °F) or higher
- Charging voltage compensation based on the temperature of the battery where the BTS is connected

1. An AC backfeed error occurs when the AC output of the inverter/charger is connected or routed back to the inverter/charger's AC input terminal or if the internal transfer relay fails.

System Components

The Freedom SW uses Xanbus, a network communications protocol developed to communicate the Freedom SW's settings and activity to other Xanbus-enabled devices.

You can configure and monitor the Freedom SW and every Xanbus-enabled device in the system using an optional Xanbus System Control Panel (SCP).

Another component is the optional Xanbus Automatic Generator Start (AGS) which allows operation with a wide range of generators, supported through a dedicated generator input. Simply, the AGS automatically starts and stops your generator.

The Freedom Sequence Intelligent Power Manager is a fully integrated power management system that provides automatic power and load management for use in recreational vehicles (RV) while receiving power from a generator or shore power. This device works in the background to prevent monitored AC loads from exceeding shore and generator breaker capacity.

See “Xanbus-enabled Products and Accessories” on page 9 for part numbers.

Xanbus System

The Xanbus system includes the Freedom SW and other Xanbus-enabled devices. The Freedom SW is the device in a Xanbus system that typically provides network power—500 mA at 12 volts DC. All of the Xanbus-enabled devices, such as the Freedom SW, the SCP, and the AGS are able to communicate their settings and activity to each other. See Figure 2.




Figure 2 Typical Xanbus System Diagram

The Xanbus-enabled designation (see below) means that this product works on a Xanbus network. Xanbus-enabled products are:


- Simple to operate and routine tasks are automated.
- Controlled by software that eliminates analog signalling errors.
- Less susceptible to interference and line loss.
- Upgradable through new software releases.

xanbus

E N A B L E D

For detailed instructions and a complete list of Xanbus-enabled devices, visit **www.xantrex.com**.


Xanbus-enabled Products and Accessories



SCP




AGS

Freedom
Sequence


3-ft cable



25-ft cable



75-ft cable



Inverter drip shield

Product/Accessory (Shown above)

| Product/Accessory (Shown above) | Product Number/s |
|--|---------------------|
| Freedom Sequence Intelligent Power Manager | 809-0912 / 809-0913 |
| Xanbus System Control Panel (SCP) | 809-0921 |
| Xanbus Automatic Generator Start (AGS) | 809-0915 |
| 3-ft network cable (0.9 m) | 809-0935 |
| 25-ft network cable (7.6 m) | 809-0940 |
| 75-ft network cable (22.9 m) | 809-0942 |
| Inverter drip shield | 808-9004 |

Product/Accessory (Not Shown)

| Product/Accessory (Not Shown) | Product Number/s |
|---|------------------|
| Freedom SW On/Off Switch | 808-9002 |
| GFCI receptacles (available on 12 VDC models only) | 808-9003 |
| Stacking cable | 808-9005 |

Freedom SW Inverter/Charger Mechanical Features




Figure 3 Freedom SW Front and Side Panels (Freedom SW 3012 shown)

Freedom SW Front and Side Panels

Before you begin to operate the Freedom SW, review the front panel features shown in Figure 4 and described in the next table. A detailed view of the LEDs and buttons on the front panel is shown in Figure 5 and described in the table next to it.

| Item | Description |
|------|--|
| 1 | Front Panel contains the Xanbus interface ports for connecting Xanbus-enabled devices, the INVERTER ENABLE and CLEAR FAULT RESET buttons, as well as various status LEDs. See Figure 5. |
| 2 | Mounting holes are used for mounting the unit. A total of eight holes are provided on the unit. |
| 3 | Two variable-speed cooling fans are used to cool the unit. Fan speed control is based on internal temperature of critical components. The two cooling fans draw airflow into the inverter around the transformer and power compartments of the unit then exhaust through the other vents. Ensure at least 3 inches (76 mm) of clearance for proper ventilation. |





Figure 4 Isometric View of the Front Panel and Fans



| Item | Description |
|------|---|
| 1 | DC terminals. |
| 2 | AC wiring compartment access panel with compartment cover on. |
| 3 | FAULT LED turns on solid if a fault condition occurs and flashes intermittently when a WARNING condition is active. |
| 4 | When AC is present and qualified, the AC IN LED will turn on solid indicating also that AC is passing through. CHARGING LED flashes intermittently when the Freedom SW is in charge mode and is producing DC output to charge your batteries. |
| 5 | INVERTER ENABLED indicates the invert mode is enabled. This is different from the inverter being “on”. When enabled the inverter can be on or off. When disabled, the inverter is always off. If AC is present and invert mode is enabled, this LED remains illuminated even though AC power is being passed through. GEN SUPPORT LED flashes intermittently when the inverter is in generator support mode and is assisting the generator. |
| 6 | INVERTER ENABLE button is used to enable or disable the inverter. |

Figure 5 Isometric View of the Front Panel and AC/DC Side Panel

| Item | Description |
|------|---|
| 7 | CLEAR FAULT RESET button is used to clear any active faults if pressed momentarily. If held down for more than three seconds, the unit will reset (reboot) itself. |
| 8 | STACKING port is used to connect two inverter/chargers together for stacked operation. This is required only for stacking in series. |
| 9 | XANBUS INTERFACE ports are used to connect Xanbus-enabled devices including the optional SCP and AGS. |

Freedom SW AC and DC Side Panels

The DC side of the Freedom SW has the equipment ground lug, the positive (+) battery terminal, and the negative (-) battery terminal plus the remote network com port and battery temperature sensor com port.




Figure 6 AC and DC Side Panel

| Item | Description |
|------|--|
| 1 | Remote (REM) jack provides connection for the Freedom Sine Wave remote panel. |
| 2 | Battery temperature sensor (BTS) jack provides connection for the battery temperature sensor (supplied). |
| 3 | Negative (-) DC terminal (black). Use a qualified personnel for connecting cables. |
| 4 | Positive (+) DC terminal (red). Use a qualified personnel for connecting cables. |
| 5 | AC Output circuit breaker reset button |
| 6 | AC Input circuit breakers reset buttons. See “Shore (Shr) setting” on page 29 and “AC In Breaker” on page 52. |
| 7 | AC knockouts provide access for AC cables (both input and output wiring). |
| 8 | AC Input screw-type terminal block . Use a qualified personnel for connecting wires. |
| 9 | AC Output screw-type terminal block . Use a qualified personnel for connecting wires. |
| 10 | Ground terminals along the tab at the bottom of the opening to the AC wiring compartment access panel. Use a qualified personnel for connecting wires. |
| 11 | Chassis ground lug connects the chassis of the Freedom SW to your system’s chassis grounding point. Use a qualified personnel for connecting wires. |

Freedom SW Supplied Accessories




Figure 7 Supplied Accessories

NOTE: If any of the supplied accessories are missing, contact customer service or any authorized dealer for replacement.

| Item | Description |
|------|---|
| 1 | Two DC terminal covers are supplied to prevent accidental contact with the DC cable connectors after installation. The red cover is for the positive cabling terminal, and the black cover is for the negative cabling terminal. |
| 2 | BTS , the Battery Temperature Sensor consists of: Connector plugs into the BTS jack on the Freedom SW. Sensor cable is 25 feet (7.6 meters). Sensor can be mounted on the side of the battery case or on the negative battery terminal. NOTE: The BTS continuously measures the temperature of the battery and adjusts the charger output for a more accurate, temperature-compensated charge. |
| 3 | Two sets of nuts and washers are used to secure DC cable ends to the DC terminals. |
| 4 | Two Xanbus network terminators are used to properly terminate each of the two ends of the daisy-chained Xanbus network. For example, if the Xanbus SCP is connected to the inverter/charger, one terminator will be plugged to the SCP, one network cable will connect both devices, and one terminator will be plugged to the inverter/charger. IMPORTANT: The Xanbus SCP may perform erratically if the Xanbus network is not properly terminated. |

Freedom Inverter/Charger Operation

Start Up Behavior

When the Freedom SW is powered up or has been reset, all of the front panel LEDs turn on and remain on for a minimum of five seconds. During this interval, the fans are also turned on as the unit executes internal diagnostics.

Out of the box from the factory, when the Freedom SW is powered up (that is, when AC and DC power sources are connected) for the first time, the inverter function is disabled by default. After powering up, the **INVERTER ENABLE** button (or the “Up” button on the SCP) can be used to enable or disable inverter function. See “Inverter Operation Using the Front Panel” on page 18 and “Enable/disable inverter function (**En Inv/Ds Inv**)” on page 29.

Storing Inverter State Feature You can enable or disable a feature called **Store InvState** which, when enabled remembers the state of the inverter function prior to a power down (that is, when AC and DC power sources are disconnected) or prior to a Standby (Power Save) mode. When the Freedom SW is powered up again or put back on

Operating mode, the inverter function reverts back to its prior state. See “To store the state of the inverter to memory:” on page 76. This feature is disabled by default.

This feature is available only to Freedom SW 2024 (PN: 815-2024).

Enable versus Disable When a function is enabled, it is allowed to occur but other conditions may have to be met before the function actually works. For example, the charger function on the Freedom SW may be enabled, but will not charge the battery unless qualified AC power is present. For more information, see “Enabling a function” and “Disabling a function” on page 24.

IMPORTANT: Review the “Important Safety Instructions” on page iii before operating the inverter/charger.

Inverter Operation Using the Front Panel

IMPORTANT: Review the “Important Safety Instructions” on page iii before operating the inverter/charger.

Once the inverter/charger is installed, you can operate it in invert mode.

To operate in invert mode from the front panel:

1. Press the **INVERTER ENABLE** button on the Freedom SW on the front panel. The **INVERTER ENABLED** LED turns on and connected loads will be energized.
2. Note that if AC is present and being passed through, the **INVERTER ENABLED** LED will still turn on to indicate inverter mode has been enabled. However, AC will continue to be passed through to the loads until conditions exist that cause AC to be disqualified, in which case the unit will transition to invert mode and power up critical loads.
3. Connect AC input power.
The charger automatically starts up when qualified AC power is connected.

To operate the inverter with the System Control Panel, refer to “Operating the Freedom SW with the SCP” on page 23.

4. Disconnect AC power from inverter input by opening the breaker or disconnect.
5. Place a load on the inverter. For example, plug a 100-watt light bulb into an outlet that the inverter is powering. Press the **INVERTER ENABLE** button on the Freedom SW. The **INVERTER ENABLED** LED turns on. The inverter should run the load using battery power.
6. To test the charger, reconnect the AC input power to allow AC to the AC input. The AC In/Charging LED should start flashing after a brief delay. Any AC loads previously powered by the inverter will also work at this time.
NOTE: On dual input models, only AC Input L1 needs to be powered for the unit to operate.
7. Remove the AC input power. The inverter/charger should transfer to invert mode immediately. (The transfer relay will make a clicking sound and the **INVERTER ENABLED** LED will turn on.) Loads should continue to operate uninterrupted.

If any part of this test fails, determine the cause before using the unit.

8. Monitor the Freedom SW Front Panel.

The indicator LEDs on the front panel show you the operating status of the Freedom SW. A description of the LEDs is provided in Table 1.

If none of the front panel LEDs are on, see “Troubleshooting” on page 87.

Table 1 Front Panel LEDs

| LED Label | Color | Status | Action (or Status Item) |
|-------------------------|----------------|---|--|
| Inverter ENABLED | Steady Green | If utility and generator AC is unavailable and operating conditions are met, the Freedom SW will produce AC voltage to power loads. | You can run your appliances from the inverter. |
| Gen Support | Flashing Green | The inverter is assisting a generator in powering loads. | You can run your appliances from the inverter. |

Table 1 Front Panel LEDs

| LED Label | Color | Status | Action (or Status Item) |
|-----------------|----------------|---|---|
| AC IN | Steady Green | When the Freedom SW is connected to a qualified AC source or a generator, the AC IN LED turns on. | You can run your appliances from an AC source like the utility grid or a generator. |
| Charging | Flashing Green | Freedom SW is connected to a qualified AC source, is charging and passing power to AC loads. | Your battery bank is being replenished and AC loads are receiving power. |
| Fault | Steady Red | A fault condition was detected on the network. | Investigate and clear the fault condition. |
| Warning | Flashing Red | A warning is detected. | Investigate by examining warning logs on SCP. |

Faults and Warnings A fault affects the operation of the unit. A manual fault requires user intervention by clearing the condition and then pressing the **CLEAR FAULT RESET**

button on the inverter/charger's front panel. See the *Xanbus System Control Panel Owner's Guide* for information on clearing faults from the SCP.

A warning alerts you to a condition that could possibly affect operation of the unit.

IMPORTANT: If you are having problems with any of your loads, refer to "Inverter Applications" on page 88.

Operating Limits for Inverter Operation

Temperature The Freedom SW series of inverter/chargers will operate at rated power continuously at 30 °C with some models capable of continuous operation at much higher ambient temperature. However, the continuous power rating at elevated ambient temperature may differ between models. See "Specifications" on page 105 for full details. In higher ambient temperatures, if the loads draw full power for an extended period of time, the unit may shut down to protect itself against overheating.

The Freedom SW series of inverter chargers feature a surge rating of 200% of rated power for five seconds at 25 °C. Operating the inverter/charger in conditions outside of power and temperature limits, however, will result in thermal shutdown and/or significantly decreased performance. In addition, operation in this range is outside the ratings covered by the regulatory approvals of the product.

Difficulty on starting loads The inverter/charger should be able to operate all AC loads rated at or below its power rating. Some high horsepower induction motors used in pumps and other motor-operated equipment require very high surge currents to start, and the inverter/charger may have difficulty starting these loads.

If you have problems starting certain loads, ensure that:

- Battery connections are tight and clean.

- DC cabling is no longer than the recommended length. Refer to the *Freedom SW Sine Wave Inverter/Chargers Installation Guide* for this information.
- AC wiring is of recommended size. Refer to the *Freedom SW Sine Wave Inverter/Chargers Installation Guide* for this information.
- Battery is of sufficient capacity and is fully charged.

NOTE: Many 24 V inverter battery banks have a capacity between 200–400 Ah and 12 V inverter battery banks have a capacity between 400–800 Ah. Refer to the *Freedom SW Sine Wave Inverter/Chargers Installation Guide* for sizing requirements.

Operating Limits for Charger Operation

By default, the maximum charger output current is the rated charger output current for the particular model. Using the SCP, you can reduce the total output if you change the maximum charge rate (**Max Chg Rate**) on the Freedom SW Basic Settings menu or Inverter Settings menu under Advanced Settings.

The charger can operate within an AC input range of 95–135 volts. The default settings are **95** and **135**, which are the **ACIn Lo Volt** and **ACIn Hi Volt** respectively. The **ACIn Lo Volt** setting has a range of **78–115** volts and the **ACIn Hi Volt** setting has between **125–140** volts.

AC Frequency The charger can also be configured to accept and operate from a wide AC source frequency of 40–68 Hz. Therefore, the Freedom SW can charge your batteries even when incoming AC voltage is less than ideal. The default settings are **45** and **55** Hz, which are the **ACIn Lo Freq** and **ACIn Hi Freq** settings respectively.

Power sharing The Freedom SW charger uses incoming AC or shore power (see following note) to charge the batteries. The charger shares incoming AC power with AC loads on Line 1 only. The AC loads have priority, which means that the charger will reduce its output with large AC

loads and increase the output again when the AC load decreases. The regulatory maximum for continuous AC loads is 80% of the breaker rating (see “**AC1 Breaker**” on page 51) that the loads are connected to. The Freedom SW senses pass-through current going to the AC load. The difference between the pass-through (load) and 80% of the **AC1 Breaker** setting is the current that is available for charging the batteries.

For example, if the AC input of the Freedom SW is from an AC panel with a 30-amp breaker, the **AC1 Breaker** setting on the SCP should be selected as **30** amps. Based on this, the charger will control the charge current so that the total current draw is equal to or less than 24 amps in this case. Should the load current be more than 24 amps, the charger output will reduce to 0 amp, but the Freedom SW will continue to supply the loads. The Freedom SW will continue to pass-through power to the loads, even if the load current exceeds the **AC1 Breaker** setting. In this case, it will be up to the user to remove/disconnect loads if tripping the AC input breaker supplying the Freedom SW is to be avoided.

NOTE: The **AC1 Breaker** setting can also be changed using the **Shr** soft key in the SCP (see “Soft Key Navigation” on page 29). **Shr** stands for shore power which refers to incoming AC power in the mobile industry.

Operating the Freedom SW with the SCP

This section contains detailed information and procedures for using your Freedom SW in conjunction with the System Control Panel (SCP).

If you're using the SCP to operate or monitor the status of the unit, you may also refer to the *Xanbus System Control Panel Owner's Guide*.

WARNING

LIMITATIONS ON USE

Do not use in connection with life support systems or other medical equipment or devices.

Failure to follow these instructions can result in death or serious injury.

The SCP provides operating, configuration, and monitoring capability for your Xanbus system.

The SCP:

- Monitors activity throughout your onboard power system.
- Displays the latest information about your inverter/charger, battery voltage level, battery charge output, and generator start and stop activity.
- Displays the settings for each Xanbus-enabled device in the system.
- Enables you to adjust the settings for each Xanbus-enabled device in the system.
- Preserves all of its settings if system power is interrupted. After power is restored, you don't have to reconfigure the SCP or any of the Xanbus-enabled devices connected to it.

This section provides information on operating the Freedom SW with the SCP. Please refer to the System Control Panel Owner's Guide for complete information on using the System Control Panel.

Using the Xanbus SCP

As shown in Figure 8, the SCP has these important features:

Display screen System information is shown on the display screen with an adjustable backlight.

Indicator LEDs Four indicator LEDs on the front panel indicate the operating status of the Xanbus system.

Push buttons Four push buttons allow you to select device menus and change or display settings. The red **STBY/ON Fault Clear** button toggles the SCP and Xanbus-enabled devices between Operating mode and Standby (Power Save) mode, if held down for more than five seconds. The button can also be used to clear any active faults or warnings by momentarily depressing the button.

System Control Panel

The Xanbus System Control Panel (SCP) provides configuration and monitoring capability for all Xanbus-enabled devices on the network. All changes to the configuration of the Freedom SW are made with the SCP.

The front panel of the Freedom SW provides limited control, including reset; charger enable and disable; and inverter enable and disable.

Enabling a function When a function is enabled, it is allowed to occur but other conditions may have to be met before the function actually works. For example, the charger function on the Freedom SW may be enabled, but will not charge the battery unless qualified AC power is present.

Disabling a function When a function is disabled, it is not allowed to occur and if it is already occurring, it is terminated immediately. Regardless of other conditions, the function will not work. For example, even if AC power is present, if the charger function is disabled, the Freedom SW will not charge the battery.

NOTE: All functions on the front panel can also be controlled from the SCP.




Figure 8 Xanbus System Control Panel (SCP)

| Item | Description |
|------|---|
| 1 | AC In/Charge LED indicates that qualified AC is present at the input of an inverter/charger. When the Freedom SW is connected to a qualified AC source like the utility grid or a generator, this LED on the SCP turns on. |
| 2 | Inverter On LED turns on when the Freedom SW is inverting using battery power. |
| 3 | Low Battery LED turns on when the battery voltage on the Freedom SW is low. |
| 4 | Fault LED indicates a detected condition that requires user attention and intervention. The Fault LED turns on when any Xanbus-enabled device connected to the network detected a fault. See “Detected Fault Types” on page 90 for the definitions of a fault and warning. |
| 5 | STBY/ON Fault Clear button is used to clear active faults on the system if pressed momentarily. It also toggles all Xanbus-enabled devices on the system between Operating and Standby (Power Save) mode when held down for more than five seconds. See “Inverter Operation Using the Front Panel” on page 18. |

| Item | Description |
|------|---|
| 6 | Screen displays menus, settings, and system information. Displays a menu screen title, four lines of menu items, and a line that contains small arrows that depict pointers to SCP buttons. |
| 7 | Func button: Cancels selection of a menu item. Returns you to the previous screen. Changes the functions of the Up and Down arrow buttons. |

| Item | Description |
|-----------|---|
| 8 (and 9) | Down (and Up) arrow buttons: Scrolls down (up) one line of text. Decreases (increases) a selected value. When the Func button is pressed to select: “ Shr ” - the down (and up) arrow buttons increment (decrement) shore power breaker capacity on a Freedom SW inverter/charger ^a . “ AGS ” - the down (and up) arrow buttons switch between different AGS Start modes (Auto, Manual-On, Manual-Off). “ Home ” - the down (and up) arrow buttons enable or disable the inverter. See “Soft Key Navigation” on page 29 for more information. |
| 10 | Enter button: Confirms selection of a menu item. Moves you to the next screen. |

a. If the Freedom Sequence power manager is installed in the power system, the shore breaker capacity on the power manager is adjusted but not the inverter/charger.

SCP Navigation

Startup Screen

This screen is shown when the Xanbus SCP first receives power from the Xanbus network.





Figure 9 Startup Screen

Viewing the SCP Home Screens

The top level screens on the Xanbus SCP are the startup screen, the **System Status** screen (Figure 10) and the device **Home** screen. After power is applied and the startup screen appears, the Xanbus SCP displays the **System Status**

screen. You can view the device **Home** screen for the Freedom SW and other devices in the system by pressing the up and down arrows.



- - Menu screen title. Every screen has one.
- - menu arrow that points to the **Enter** button. The menu arrow is called a soft key. See "Soft Key Navigation" on page 29 for more information.

Figure 10 System Status

System Status Screen The **System Status** screen appears after the startup screen. It displays aggregated status information for the entire power system. For example, a single system might have two Xanbus network-connected Freedom SWs, one Xanbus AGS module, and one Xanbus SCP all connected to a single battery bank.

Operating the Freedom SW with the SCP

The **System Status** screen always features a **menu** arrow pointing to the **Enter** button. Pressing **Enter** takes you to the **Select Device** menu screen. For more information, see “Reading the System Status Screen” on page 33.

IMPORTANT: If you are uncertain which Xanbus SCP menu screen you are viewing, you can return to the starting point—the **System Status** screen—by pressing the **Func** button repeatedly until the screen stops changing.

Select Device Screen As mentioned, this screen appears when the **Enter** button is pressed from the System Status screen. It lists all Xanbus-enabled devices including options to select System Settings and Clock.




Figure 11 Freedom SW Select Device Screen

To display the Select Device menu:

- ◆ While viewing the **System Status** screen, press **Enter**.

Device Setup Screen The Device Setup screen is shown when a Xanbus-enabled component is selected from the Select Device screen. For example, below is an example of a Device screen for the Freedom SW 3012 inverter/charger. **Device Setup** menus display status information and changeable settings. Changeable settings are identified by the square brackets [] around values in the right-hand column.

To display the Setup menu for a device:

- ◆ Highlight the device name on the **Select Device** menu screen and press **Enter**.

-Or-

From the device **Home** screen, press **Enter**.

Soft Key Navigation

Soft keys are the objects on the fifth line of the System Status screen. The soft keys have arrows that point to a corresponding physical button such as the **Enter**, Up arrow, Down arrow, and **Func** buttons. They are called as such because they perform functions in conjunction with pressing the corresponding SCP button that each arrow points to.




Figure 12 Freedom SW Device Screen




Figure 13 Soft Keys

In the next page, it will show how to navigate the soft keys to:

- Enable/disable inverter function (**En Inv/Ds Inv**)
- Enable/disable charger function (**EnChg/DsChg**)
- Change shore breaker ratings (**Shr**) - see also “**AC In Breaker**” on page 52
- Select AGS trigger modes (**AGS**)




Figure 14 Freedom SW System Status Screen - Soft Key Navigation

Viewing the Firmware Revision Number

You may need to view the firmware revision number (F/W Rev.) of the Freedom SW when troubleshooting the unit with authorized service personnel.

To view the firmware revision number:

- From the **System Status** screen, press the **Enter** button.
The **Select Device** menu screen appears.
- From the **Select Device** screen, press the **Enter** button.
The **System Settings** menu screen appears.
- From the **System Settings** screen, press the down arrow button to highlight **View Device Info**
- Press **Enter**.
The **Device Info** screen appears.
- Read the displayed information.
The series of numbers and letters opposite **F/W Rev.** is the firmware revision number.
- Press **Func** (3x) to return to the **System Settings** menu.

To view the F/W Rev. from the System Status screen:

1 System Status

| | | | |
|---------|---------------------------------|--------|------|
| Battery | 12.1V | -257A | 84 F |
| BatLev | <div style="width: 50%;"></div> | Invert | |
| Load | 120V | Invert | 12A |
| AC In | 0V | | 0A |

↓menu ↓EnInv ↓EnChg Shr ↓

Enter ▲ ▼ Func

2 Select Device

System Settings

FSW3012 00

XAGS 00

XSCP

Enter ▲ ▼ Func

3 System Settings

Invert

AC Charge

System Mode [Enabled]

Cascading

Enter ▲ ▼ Func

4 System Settings

View Fault List

View Warning List

Clear All Flts/Wrns

View Device Info

Enter ▲ ▼ Func

5 Device Info

| | |
|-------------------------|----------------------------|
| FSW3012 | ← Device Name |
| Model # 815-3012 | ← Model Number |
| Serial # 100529833000 | ← Serial Number |
| F/W Rev. 1.00.00 BN 107 | ← Firmware Revision Number |

Enter ▲ ▼ Func

6

Setting the Time and Date

Freedom SW advanced features such as time-stamped events (faults, warnings, and logged historical data) require that the system be set to the correct time. The Xanbus SCP has an internal clock that controls the time for all Xanbus-enabled devices in the system. You can set the time, time format, and date on the **Clock** menu. The **Clock** menu is accessible on the **Select Device** menu.

For more information, see refer to the *Xanbus SCP Owner's Guide*.

Using the STBY/ON Fault Clear Button

The **STBY/ON Fault Clear** button has two functions.

The **STBY/ON Fault Clear** is used to clear active faults on the system if pressed momentarily. It also toggles all Xanbus-enabled devices on the system between Operating and Standby (Power Save) mode when held down for more than five seconds.




Figure 15 Xanbus SCP **STBY/ON Fault Clear** Button

Reading the System Status Screen

The **System Status** screen displays:

- Battery-related information (see Line 2)
- Battery level and inverter/charger operating state (see Line 3)
- Load information (see Line 4)
- AC Input information (see Line 5)




Table 2 System Status Screen

| | |
|--------|---|
| Line 1 | Label: “System Settings” |
| Line 2 | Label: Battery Field 1: Total battery current. Negative value if the battery is discharging and positive value when charging. Field 2: Battery voltage Field 3: Battery temperature ^a . Also, displays the highest temperature between stacked inverters that are installed. |
| Line 3 | Label: BatLev Field 4: Displays a bar graph showing the approximate battery level. Field 5: Freedom SW inverter/charger operating state |
| Line 4 | Label: Load Field 6: Inverter output voltage at load terminals of the inverter/charger. Voltage is reported by the Master unit if more than one inverter/charger is installed. Field 7: Master current ^b Field 8: Sum of all load current from both inverter and charger. Also, it displays Slave (or L2 Master) current ^d . |

Table 2 System Status Screen

| | |
|--------|---|
| Line 5 | <p>Label: AC In</p> <p>Field 9: AC input voltage at AC In terminals of the inverter/charger. Voltage is reported by the Master unit if more than one inverter/charger is installed.</p> <p>Field 10: Master current^b</p> <p>Field 11: Sum of all L1 AC input current^c from both inverter and charger. Sum of all load current from both inverter and charger. Also, it displays Slave (or L2 Master) current^d.</p> |
|--------|---|

a. The unit of temperature can be changed in the SCP Config menu screen.

b. When in a stacked inverter configuration.

c. Only L1 AC input is taken into account. L2 AC input current is not included in the sum in Freedom SW inverter/charger models where there is L2 AC input.

d. In a single unit setup, the Slave (or L2 Master) will display 0A all the time mainly because of the absence of a second unit. If two units are stacked, the Master and Slave (or L2 Master) current will display the appropriate current values.

Reading the Freedom SW Device Setup Screen

The Freedom SW Device **Setup** menu screen displays real-time operational data (status information) specific to the Freedom SW. The Freedom SW status changes according to the states described in Table 4, “Freedom SW Device Setup Screen Operating States (Modes)” on page 37.

The Freedom SW Device **Setup** menu screen has two segments. The first segment (lines 2 to 5) displays status information and appears first in the screen’s initial four lines. The second segment (lines 6 to 15) contains selectable fields when the Down arrow button is pressed (scrolling down the device setup screen). These selectable fields are configurable, meaning their values can be changed from within the setup screen or they bring up another screen (another level of configuration). For information on how to configure the Freedom SW inverter/charger, see “Configuring the Freedom SW using the SCP” on page 39.

To view the Freedom SW Setup menu screen:

1. On the **Select Device** screen, press the Down arrow button until the **FSW3012 00**¹ is highlighted.
2. Then, press **Enter** to display the **FSW3012 00: Setup** screen which is the device setup menu screen.
3. Press the Up and Down arrow buttons view status information fields and move between selectable fields.

Select Device

System Settings

FSW3012 00

XAGS 00

XSCP

① STATION Fault Clear

② Press **Enter** to bring up the device setup screen.


③ Press these buttons to scroll up and down the Device Setup fields.

FSW3012 00: Setup


| Mode | Invert | | |
|---------|--------|--------|-----|
| Battery | 11.8V | -88.0A | N/A |
| Load | 900W | 120V | 7A |
| AC In | 0V | 0A | 0Hz |

① STATION Fault Clear

1. Typical device ID for a single installed Freedom Inverter/Charger. The second unit has a device name **FSW3012** is followed by **01**.



Complete list Freedom SW Device Setup fields.



* appears only when **Enter**, Up, and Down arrow buttons are pressed together.




Table 3 Device Setup Screen Status Information

| | |
|--------|--|
| Line 1 | Label: “FSW3012 00: Setup” |
| Line 2 | Label: Mode Field 1: Freedom SW operating mode or “operating state” (see Table 4 on page 37). |
| Line 3 | Label: Battery Field 2: Total battery current. Negative value if the battery is discharging and positive value when charging. Field 3: Battery voltage Field 4: Battery temperature. Displays the highest temperature when reading two inverters that are installed. Displays N/A when there is no BTS attached. |
| Line 4 | Label: Load Field 5: Total power drawn by AC loads connected to the unit. Field 6: Inverter output voltage at load terminals of one inverter/charger unit. Field 7: Sum of all current drawn out by the AC loads. |

Table 3 Device Setup Screen Status Information

| | |
|---|---|
| Line 5 | <p>Label: AC In Field 8: AC input voltage at AC In terminals of the inverter/charger. Field 9: Sum of all current drawn into one inverter/charger unit. Field 10: AC input frequency</p> |
| STBY/ON Fault Clear button | Press momentarily to clear all faults on all devices on the network. Press and hold for five seconds to switch all devices in the network between operating and standby modes. |
| Enter, Up arrow, Down arrow buttons (pressed simultaneously) | Switches between Basic Settings and Advanced Settings. |

Table 4 Freedom SW Device Setup Screen Operating States (Modes)

| State (Mode) | Displayed When... |
|---------------|---|
| Invert | The Freedom SW is supplying power to loads by inverting power from the batteries. AC input from the utility or generator is absent or out of nominal range. |

Table 4 Freedom SW Device Setup Screen Operating States (Modes)

| State (Mode) | Displayed When... |
|----------------------|--|
| Qualifying AC | The Freedom SW is determining if AC input is within a usable voltage and frequency range. Qualifying AC is also displayed when the Freedom SW is awaiting application of AC power or a command to enable invert mode. |
| Charging | The Freedom SW is charging the batteries from qualified AC input from the utility grid or a generator. The charge state is in transition to either bulk, absorption, float, or equalize. AC input is also passed through to the load while charging. |
| Bulk | The Freedom SW is bulk charging the batteries from qualified AC input from the utility grid or a generator. AC input is also passed through to the load while bulk charging. |
| Absorption | The Freedom SW is absorption charging the batteries from qualified AC input from the utility grid or a generator. AC input is also passed through to the load while absorption charging. |

Table 4 Freedom SW Device Setup Screen Operating States (Modes)

| State (Mode) | Displayed When... |
|-------------------|--|
| ABS Finish | One Freedom SW unit has completed the absorption stage and is waiting for other Freedom SWs in the system to complete absorption. This status can occur only when there is another Freedom SW also charging the battery. |
| Float | The Freedom SW is float charging the batteries from qualified AC input from the utility grid or a generator. The Freedom SW is set for three-stage charging. AC input is also passed through to the load while float charging. |
| Fault | The Freedom SW has an active fault. The Fault/Warning LED on the Xanbus SCP is on. |

| State (Mode) | Displayed When... |
|--------------------|--|
| Gen Support | There is AC input from the generator, and the Freedom SW is supporting the generator by supplying additional power to the critical loads. See “Gen Support” on page 67. |
| Search | Search mode is enabled and the Freedom SW is standing by, waiting to begin inverting. See “Changing Configurable Settings From The Device Setup Menu Screen” on page 42. |
| Passthru | The AC connected to the AC1 or AC2 input is passing directly through the Freedom SW to the loads. The batteries are not being charged in this state. |
| Equalize | Equalization has been turned on and the Freedom SW is equalizing the batteries after completing a full charge cycle. |

Configuring the Freedom SW using the SCP

This section contains information about all configurable settings and procedures for the Freedom SW.

It provides information on using the SCP to configure the Freedom SW settings for optimal performance. Please refer to the *Xanbus System Control Panel Owner's Guide* for detailed information on how to use the SCP.

System Menu Map

Figure 16 provides a map of how the SCP screens and menus are organized. The order of devices appearing on the SCP will vary, depending on the order in which they've been connected to the network.




Figure 16 SCP System Menu Map

Viewing the System Status Screen

The System Status screen displays system activity. The information appearing on the System screen varies with the status of the inverter/charger. See “Reading the System Status Screen” on page 33. Go back to “Reading the Freedom SW Device Setup Screen” on page 35 for an explanation of the different states of the inverter/charger. For example, Figure 17 shows the Freedom SW in the bulk stage of charging.




Figure 17 Bulk System Screen (Example)

You cannot select or change any of the information on the System Status screen. If you would like to view more detailed information, press the **Enter** button (indicated by the menu arrow) to go to the Select Device menu.

Viewing the Select Device Menu

The Select Device menu is where you can view a list of all the Xanbus-enabled devices in your power system.

At least two devices are sure to appear together with System Settings and Clock – the Freedom SW Inverter/Charger and the Xanbus SCP. Other devices such as the Xanbus AGS and the Freedom Sequence Intelligent Power Manager appear only when they are connected and installed.



Figure 18 Select Device Screen

Selecting the Freedom SW from the Select Device Menu

To view the Freedom SW Setup menu screen:

- ◆ Follow the procedures on “To view the Freedom SW Setup menu screen:” on page 35.

You can view and change Freedom SW settings from the **Setup** menu screen. The **Basic Settings** and **Advanced Settings** bring up their menu screens for which other configurable settings can be found.




Figure 19 Device Setup Menu Screen

Changing Configurable Settings From The Device Setup Menu Screen

The Freedom SW can only be configured using the Xanbus SCP. Follow the procedure in “To view the Freedom SW **Setup** menu screen:” on page 35 to bring up the device setup screen for the Freedom SW inverter/charger.

| FSW3012 00: Setup | | Line 1 | |
|-----------------------|-----------------------|------------------|---------|
| Status | Mode | Invert | Line 2 |
| | Battery | 11.8V -88.0A N/A | Line 3 |
| | Load | 915W 120V 7A | Line 4 |
| | AC In | 0V 0A 0Hz | Line 5 |
| | Advanced Settings* | | Line 6 |
| Configurable Settings | Inverter | [Enabled] | Line 7 |
| | Search Mode | [Disabled] | Line 8 |
| | Charger | [Disabled] | Line 9 |
| | Force Chg State | | Line 10 |
| | Equalize | [Disabled] | Line 11 |
| | Desired Mode | [Standby] | Line 12 |
| | Clear Faults Warnings | | Line 13 |
| | View Device Info | | Line 14 |
| | Basic Settings | | Line 15 |

NOTE: The Xanbus SCP only displays four lines of the device Setup menu at once. To view configurable settings, press the Down arrow button.

* appears only when **Enter**, **Up**, and **Down** arrow buttons are pressed together.

Figure 20 Freedom SW Device Setup Menu

As discussed in “Reading the Freedom SW Device Setup Screen” on page 35 the Freedom SW Device Setup menu screen has two segments. The first segment (lines 2 to 5)

displays status information and appears first in the screen’s initial four lines. The second segment (lines 6 to 15) contains selectable fields which are configurable settings.

These configurable settings are:

- Advanced settings
- Inverter
- Search mode
- Charger
- Force charge
- Equalize
- Desired mode
- Clear fault settings
- View device info
- Basic settings

Only nine of these settings are displayed at a time. The **Advanced Settings** (Line 6) is not initially listed and only lines 7 through 15 appear. When the Advanced Settings is listed, it will appear on top of the list for configurable settings and the setup screen will display lines 6 through 14.

See Table 5, “Configurable Settings” on page 44 for information on each setting.

To select and change a configurable setting:

1. On the setup menu, press the Down arrow (or Up arrow) button to highlight the setting you want to change.
2. Press **Enter** to highlight the current value of the setting.
3. Press the Up arrow or the Down arrow button to change the value. Hold down the button to scroll through a large range of values quickly.

The previously set value (or default value) appears with an asterisk (*) beside it.

4. Press **Enter** to select and confirm the value.
5. If you have another setting to change, return to step 1.

-Or-

If you have no more settings to change, press **Func** until the Xanbus SCP displays the desired screen or menu.

IMPORTANT: If you have no more settings to change, it is recommended to leave the **Setup** menu in the basic settings format to help prevent unintentional configuration. If the **Setup** menu displays **Advanced Settings**, press **Enter** + Up arrow + Down arrow at the same time. The Setup menu should then display **Basic Settings** as the last item on the menu.




Figure 21 Selecting and Changing a Configurable Setting

Table 5 Configurable Settings

| Item | Description |
|------------------------|--|
| Inverter | Enables or disables the inverter function of the Freedom SW. When enabled, the unit will invert power from the batteries assuming there is enough charge in the batteries. Default value is Enabled. |
| Search Mode | Enables or disables the Search Mode function of the Freedom SW. See “Using Search Mode” on page 45 for more information. Default value is Disabled. |
| Charger | Enables or disables the charger function of the Freedom SW. When enabled, the unit will charge the batteries when AC is available. For more information on configuring the charger settings go to “Charger Settings Menu” on page 60. Default value is Enabled. |
| Auto Chg Enable | Forces the Freedom SW to charge the batteries when qualified input AC is detected even when the charger function is disabled. |

Table 5 Configurable Settings

| | |
|-----------------------------|--|
| Equalize | Initiates the battery equalization process. See “Equalization Procedure” on page 47 to enable the procedure. Default value is Disabled. |
| Desired Mode | Switches between Operating and Standby (Power Save) modes. Default value is Operating. |
| Clear Faults Warning | Clears any active faults and warnings. |
| Basic Settings | See “Changing Freedom SW Basic Settings” on page 48 for more information. |
| Advanced Settings | See “Changing Freedom SW Advanced Settings” on page 53 for more information. |

Follow procedures on “To select and change a configurable setting:” on page 43 to change the settings.

Using Search Mode

Why use Search mode? Search mode allows the inverter to selectively power only items that draw more than a certain amount of power, which can result in power savings. The Freedom SW has a no-load power draw of about 28 watts. Enabling search mode reduces this power draw to less than 8 watts. Search mode operates differently in single-unit and multi-unit installations.

Single units When a single Freedom SW has search mode enabled, the inverter sends electrical search pulses through its AC output. These search pulses look for connected AC loads. The delay between search pulses is set using the **Search Delay** setting. After a load larger than the **Search Watts** setting is detected, the inverter starts producing AC output.

Double units When configured for 120/240-volt series stacking, each inverter/charger operates independently in search mode and attempts to detect loads connected to its terminals only.

To use search mode in parallel stacking, the Master unit must have **Search Mode** disabled. The Slave unit must have **Search Mode** enabled.

IMPORTANT: The Slave unit continuously monitors the output of the Master unit. If the Master unit has more than 60% of the rated load (for example, 1800 watts on Freedom SW 3012), the Slave unit will assist the Master and the two will share the load equally. Should the load on the Master drop below 20% of rated load (600 watts for Freedom SW 3012), the Slave unit disengages and returns to a waiting state.

When to set up Search mode The search mode feature is only valuable if the inverter can spend a fair amount of time “sleeping” each day. Therefore, if search mode is to be used it must be adjusted properly. The initial adjustment should be made so that the inverter comes on only when needed.

Certain types of loads can cause search mode to work unexpectedly. These types of loads are described in “Inverter Applications” on page 88. If these kinds of loads are in the system, follow the suggestions given to eliminate the problem.

If the problem loads cannot be eliminated, there are two work-around solutions:

1. Disable search mode from the main Freedom SW Setup menu, causing the inverter to always remain at full output voltage.
2. Use a search-friendly companion load whose only purpose is to be switched on to wake up the inverter to power the load that is unable to bring the inverter out of search mode.

NOTES:

- Search mode, by function, cannot work with clocks and timers or devices that need power 24 hours a day. Examples of devices with timers include video recorders, coffee makers with brew timers, refrigerators, and freezers with defrost timers. Examples of devices that need power 24 hours a day include telephone answering machines, alarm systems, motion detection lights, and some thermostats.
 - When the inverter is searching the output for loads, lights that have a wattage lower than this setting may flash momentarily.
-

Equalization Procedure

To start equalizing the batteries, do one of the following:

- Apply AC voltage and ensure that the inverter/charger transfers AC and starts charging.
- On the Xanbus Setup menu, highlight **Equalize** and select **Enable**.

The unit will proceed and execute a complete bulk and absorption charge before transitioning to equalize.

IMPORTANT: The inverter/charger will not perform equalization if AC is not present, the charger is disabled, or the selected battery type does not support equalization.

If any of these cases happen, a warning is issued

If the Freedom SW will not perform the equalization, see “Detected Warning Types and Behavior” on page 92.

WARNING

EXPLOSION HAZARD

Equalize charge flooded or vented batteries only. Hydrogen and oxygen gases are produced when batteries are equalize charged. Provide adequate ventilation and remove all sources of ignition to prevent explosion.

Failure to follow these instructions can result in death or serious injury.

IMPORTANT: In a system where more than one device is capable of equalizing batteries (such as stacked Freedom SWs), there is no system-wide equalization command for all devices. To equalize with two devices, each would have to be enabled individually. Alternatively, equalization can be performed using only one device. During the equalization process, one device applies the equalization charge while the other devices continue to operate in synchronized charge mode, typically in float (three-stage charging) or no-float (two-stage charging).

Changing Freedom SW Basic Settings

Basic Settings menu The Freedom SW configuration settings can be viewed in basic format (see “Selecting Basic Settings From the Device Setup Screen” on page 49). The basic settings include configuration items you may have to adjust routinely, or as part of initial setup. It provides access to basic control of the inverter/charger.

Temporary versus permanent The Freedom SW unit stores its configuration in its onboard memory which holds configuration values even during power cycling or restart events. The Freedom SW allows the user to make changes to the configuration settings at any time the unit is powered and communicates with the SCP or a Xanbus configuration tool. This is true for Basic Settings as well as Advanced Settings (page 53).

Any configuration setting changes will be temporary, that is, they will be lost after a power cycle or restart. In order to make the setting permanent, they must be saved in the onboard memory by placing the unit in Standby (Power Save) mode. For instructions on how to put the unit in Standby (Power Save) mode, see “Using the STBY/ON Fault Clear Button” on page 32. While the unit is in the Standby (Power Save) mode the configuration changes will be immediately saved in the onboard memory. For more information on operating states (modes), see page 37.

To select the Basic Settings menu screen:

1. On the **FSW3012 00: Setup** screen (Figure 22), press the Down arrow button until **Basic Settings** is highlighted.



Figure 22 Selecting Basic Settings From the Device Setup Screen

2. Then, press **Enter** to display the **FSW3012 00: Basic** screen which is the basic settings menu screen.
3. Press the Up and Down arrow buttons to move between selectable fields.


The Freedom SW basic settings include menus for configuring:

- Battery type
- Battery capacity
- Maximum charging rate
- Charging cycle
- Recharging volts
- AC In breaker rating
- Low battery cutout value

See Table 7, “Basic Settings” on page 51 for information on each setting.

Configuring the Freedom SW using the SCP

An overview of the Freedom SW menu structure is shown below. The SCP displays the Freedom SW basic settings menu.



Follow procedures on "To select and change a configurable setting:" on page 43 to change the settings.

Figure 23 Menu Map of the Freedom SW Basic Settings

Table 6 Setting Defaults and Ranges

| Model | Freedom SW 2012 / 3012 | | | Freedom SW 2024 / 3024 | | |
|-----------------------------------|------------------------|---------------------------|--------|------------------------|---------------------------|--------|
| Item | Default | Min | Max | Default | Min | Max |
| Batt Type | Flooded | Flooded, Gel, AGM, Custom | | Flooded | Flooded, Gel, AGM, Custom | |
| Batt Capacity 2000-watt models | 250Ah | 50Ah | 2000Ah | 250Ah | 50Ah | 1000Ah |
| Batt Capacity 3000-watt models | 440Ah | | | 440Ah | | |
| Max Chg Rate | 100% | 10% | 100% | 100% | 10% | 100% |
| Charge Cycle | 3Stage | 3Stage, 2StgNoFloat | | 3Stage | 3Stage, 2StgNoFloat | |
| ReCharge Volts | 12.5V | 11.0V | 13.5V | 25.0V | 22.0V | 27.0V |
| AC1 Breaker | 30A | 5A | 30A | 30A | 5A | 30A |
| Low Batt Cut Out | 10.5V | 10.0V | 12.0V | 21.0V | 20.0V | 24.0V |

Table 7 Basic Settings

| Item | Description |
|----------------------|--|
| Batt Type | Sets the system battery chemistry and type: Flooded, AGM, Gel, and Custom. Selecting Custom displays the Custom Settings item, which allows you to adjust the settings for each charging stage. |
| Batt Capacity | Selects the system battery capacity in amp hours. Setting the battery capacity to 0 resets the charging current to its default values. Zero Ah battery capacity implies there is no absorption exit current criteria and absorption only exits when the absorption timer (default 3hrs, range 1min-8hr) expires. |

Table 7 Basic Settings

| | |
|-----------------------|--|
| Max Chg Rate | <p>Sets the percentage of the maximum DC output current that is available to the charger. The maximum DC output current for different models is:</p> <p>Freedom SW 2012 —100 ADC Freedom SW 3012 —150 ADC Freedom SW 2024 —50 ADC Freedom SW 3024 —75 ADC</p> <p>If two Freedom SWs are charging the same battery bank, set each inverter's Max Chg Rate to 1/n of the desired charge rate (where n is the number of inverter/chargers).</p> |
| Charge Cycle | <p>Sets the charging method: 3-Stage (bulk, absorption, float) or 2StgNoFloat (bulk, absorption, no float).</p> |
| ReCharge Volts | <p>Sets the recharging volts to tell the charger to initiate charging when the battery drains past the value setting.</p> |
| AC In Breaker | <p>Set the breaker limit of incoming AC.</p> |

Table 7 Basic Settings

| | |
|-------------------------|--|
| Low Batt Cut Out | <p>Low Battery Cut Out (LBCO) controls when the inverter stops producing AC output due to a low battery voltage condition. The inverter will stop producing AC output only after this level has been reached for the period of time set by the LBCO Delay. This setting is not temperature compensated.</p> |
|-------------------------|--|

Changing Freedom SW Advanced Settings

Advanced Settings menu The advanced settings option gives you access to the full range of Freedom SW settings, including everything displayed on the basic menu. As a safeguard against unintended advanced configuration, the Xanbus SCP displays the basic settings by default. To view the advanced settings, you must perform a special keypress (see “Selecting Advanced Settings From the Device Setup Screen” on page 54). See also “Temporary versus permanent” on page 48.

NOTE:

This keypress enables the advanced settings for every device in the system. After performing the keypress, **Advanced Settings** appears in the list and **Basic Settings** disappears.

CAUTION

FIRE AND ELECTRICAL SHOCK HAZARD

Familiarize yourself with advanced settings and the system-wide impact of changing those settings. The advanced settings are intended for qualified installation/service personnel only. Setting parameters incorrectly could damage connected equipment (such as batteries) or could severely affect the performance of your system. Incorrect charging configuration can lead to battery damage and risk of fire.

Failure to follow these instructions can result in minor or moderate injury.

The Freedom SW advanced settings include menus for configuring:

- Inverter settings (see page 57)
- Charger settings (see page 60)
- AC transfer limit settings (see page 65)
- Generator support settings (see page 67)
- Stacking operation, including customizing the default model name of the Freedom SW, and setting its network device number. Setting the device number is important when two Freedom SWs are on the Xanbus network and sharing connections such as AC loads, utility grid, and generator. The device number is also used when configuring paralleled Freedom SWs for Master-Slave operation (see page 69)
- Restoring default settings (see page 74) and other advanced features (see page 75)

Freedom SW advanced menu screen lists status information and settings which require that you understand and plan for the changes you make. You may not have to adjust these settings as part of regular operation.

Configuring the Freedom SW using the SCP

The SCP shows the Freedom SW basic menu by default. To view the advanced settings menu, you have to activate it by following the procedure below.

To select the Advanced Settings menu screen:

1. On the **FSW3012 00: Setup** screen (Figure 24), press the **Enter**, Up arrow, Down arrow buttons simultaneously to make **Advanced Settings** appear in the list.
2. On the **FSW3012 00: Setup** screen, press the down arrow button until **Advanced Settings** is highlighted.




Figure 24 Selecting Advanced Settings From the Device Setup Screen

3. Then, press **Enter** to display the **FSW3012 00: Adv** screen which is the advanced settings menu screen.
4. Press the Up and Down arrow buttons to move between selectable fields.

IMPORTANT: The Basic Settings and Advanced Settings menu screens do not appear at the same time. You have to perform the preceding procedure to switch between having Basic Settings or Advanced Settings appear on the device setup screen.

An overview of the Freedom SW advanced settings menu structure is shown below and the next page.




Figure 25 Menu Map of the Freedom SW Advanced Settings 1




Figure 26 Menu Map of the Freedom SW Advanced Settings 2

Inverter Settings Menu

The **Inverter Settings** menu contains settings that control when the Freedom SW starts and stops producing AC output.

| FSW3012 00: Inv Settings | |
|--------------------------|---------|
| Low Batt Cut Out | [11.0] |
| LBCO Delay | [10sec] |
| Hi Batt Cut Out | [15.5V] |
| Search Watts | [50W] |
| Search Delay | [2sec] |

Follow procedures on "To select and change a configurable setting:" on page 43 to change the settings.

Figure 27 Inverter Settings Menu Screen

Table 8 Setting Defaults and Ranges

| Model | Freedom SW 2012 / 3012 | | | Freedom SW 2024 / 3024 | | |
|------------------|------------------------|-------|--------|------------------------|-------|--------|
| | Default | Min | Max | Default | Min | Max |
| Low Batt Cut Out | 10.5V | 10.0V | 12.0V | 21.0V | 20.0V | 24.0V |
| LBCO Delay | 10sec | 0sec | 600sec | 10sec | 0sec | 600sec |
| Hi Batt Cut Out | 16.5V | 14.5V | 17.0V | 33.0V | 29.0V | 15.5V |
| Search Watts | 50W | 25W | 250W | 50W | 25W | 250W |
| Search Delay | 2sec | 1sec | 25sec | 2sec | 1sec | 25sec |

Table 9 Inverter Settings Description

| Item | Description |
|-------------------------|--|
| Low Batt Cut Out | Low Battery Cut Out (LBCO) controls when the inverter stops producing AC output due to a low battery voltage condition. The inverter will stop producing AC output only after this level has been reached for the period of time set by the LBCO Delay . This setting is not temperature compensated. |
| LBCO Delay | LBCO Delay controls how long the inverter is allowed to operate at or below the Low Batt Cut Out level before turning off due to a low battery voltage condition. The inverter will stop producing AC output only after the Low Batt Cut Out level has been reached for this uninterrupted period of time. Once the inverter has shut off, the battery voltage must rise 2 volts above the Low Batt Cut Out setting (4 volts for 24-volt systems) for inverter operation to resume. |

Table 9 Inverter Settings Description

| Item | Description |
|------------------------|---|
| Hi Batt Cut Out | Hi Batt Cut Out sets the maximum battery voltage at which the inverter will operate. If the battery voltage exceeds this limit for more than one minute, the Freedom SW displays a fault message and shuts down. The inverter will not support AC loads when in this condition. If a qualified AC source is present, the unit passes AC through to the loads. The inverter automatically restarts when the voltage drops to 1.5 volts (12 volt system) or 3 volts (24 volt system) below the Hi Batt Cut Out setting. If battery voltage continues to rise after shutdown, an external charger may still be charging the batteries. The Freedom SW cannot control how external chargers operate. |
| Search Watts | Search Watts sets the Freedom SW's search sensitivity when search mode is enabled. When a load larger than this setting is present, the inverter starts producing AC output. Enabling search mode from the Setup menu (see page 57) can minimize power draw from the battery during periods of low demand from loads. Also see "Using Search Mode" on page 45. |

Table 9 Inverter Settings Description

| Item | Description |
|---------------------|--|
| Search Delay | Search Delay sets the time between search pulses. When searching for loads, the Freedom SW sends out search pulses to determine if a load is present. If the Freedom SW finds a load above the Search Watts setting, the inverter turns on. Freedom SW power draw while in search mode decreases when Search Delay is increased, but the Freedom SW's response time to active loads is slower. |

Using the Low Battery Cut Out and LBCO Delay Settings

The **Low Batt Cut Out** setting is the lowest battery voltage level acceptable for use by the inverter. When the batteries discharge to the **Low Batt Cut Out** setting, and are held at or below this level for the **LBCO Delay** time, the inverter output shuts down and transfers any available AC source (generator or grid) to the charger to bring the battery level back above the **Low Batt Cut Out** setting. After shutdown, the inverter does not support any AC loads, and AC loads must be powered by either a generator or utility power.

- If using an automatic generator starting system, it is recommended to set the Xanbus AGS voltage trigger setting higher than the Freedom SW **Low Batt Cut Out** voltage.
- Although not recommended, if using an automatic generator starting system with the start trigger set to the same voltage as the LBCO voltage, do not set the **LBCO Delay** to less than the amount of time it takes the generator to start and connect.

Otherwise – in both of the scenarios above – inverter output turns off before the generator automatically starts, causing the battery voltage to recover slightly. This may then stop the Xanbus AGS from starting the generator or result in the Freedom SW cycling on and off multiple times before the generator automatically starts.

Charger Settings Menu

The **Charger Settings** menu provides options for configuring the Freedom SW to operate from your battery bank.

| FSW3012 00: Chg Settings | |
|--------------------------|---------------------------------|
| Batt Type [Flooded] | [*Flooded] [Gel] [AGM] [Custom] |
| Custom Settings | |
| Batt Capacity [440Ah] | |
| Max Chg Rate [100%] | |
| Charge Cycle [3-Stage] | [*3-Stage] [2StgNoFloat] |
| ReCharge Volts [12.5V] | |
| Absorb Time [180min] | |
| Auto Recharge [Enabled] | [*Enabled] [Disabled] |
| Default Batt Temp [Warm] | [*Warm] [Hot] [Cold] |

Follow procedures on "To select and change a configurable setting:" on page 43 to change the settings.

Figure 28 Charger Settings Menu Screen

Table 10 Setting Defaults and Ranges

| Model | Freedom SW 2012 / 3012 | | | Freedom SW 2024 / 3024 | | |
|-----------------------------------|------------------------|---------------------------|--------|------------------------|---------------------------|--------|
| | Default | Min | Max | Default | Min | Max |
| Batt Type | Flooded | Flooded, Gel, AGM, Custom | | Flooded | Flooded, Gel, AGM, Custom | |
| Batt Capacity 2000-watt models | 250Ah | 50Ah | 2000Ah | 250Ah | 50Ah | 2000Ah |
| Batt Capacity 3000-watt models | 440Ah | | | 440Ah | | |
| Max Chg Rate | 100% | 10% | 100% | 100% | 10% | 100% |
| Charge Cycle | 3Stage | 3Stage, 2StgNoFloat | | 3Stage | 3Stage, 2StgNoFloat | |
| ReCharge Volts | 12.5V | 11.0V | 13.5V | 25.0V | 22.0V | 27.0V |
| Absorb Time | 180min | 1min | 480min | 180min | 1min | 480min |
| Auto ReCharge | Enabled | Enabled, Disabled | | Enabled | Enabled, Disabled | |
| Default Batt Temp | Warm | Hot, Warm, Cold | | Warm | Hot, Warm, Cold | |

Table 11 Charger Settings Menu Description

| Item | Description |
|------------------------|--|
| Batt Type | Sets the system battery chemistry and type: Flooded , AGM , Ge1 , and Custom . Selecting Custom displays the Custom Settings item, which allows you to adjust the settings for each charging stage. |
| Custom Settings | Displays the Custom Battery Settings menu, where you can adjust settings specific to your battery type and installation. It is only displayed if Custom is selected as the Batt Type . |
| Batt Capacity | Selects the system battery capacity in amp hours. Setting the battery capacity to 0 resets the charging current to its default values. Zero Ah battery capacity implies there is no absorption exit current criteria and absorption only exits when the absorption timer (default 3hrs, range 1min-8hr) expires. |

Table 11 Charger Settings Menu Description

| Item | Description |
|-----------------------|---|
| Max Chg Rate | Sets the percentage of the maximum DC output current that is available to the charger. The maximum DC output current for different models is: Freedom SW 2012 —100 ADC Freedom SW 3012 —150 ADC Freedom SW 2024 —50 ADC Freedom SW 3024 —75 ADC If two Freedom SWs are charging the same battery bank, set each inverter's Max Chg Rate to 1/n of the desired charge rate (where n is the number of inverter/chargers). |
| Charge Cycle | Sets the charging method: 3Stage (bulk, absorption, float) or 2StgNoFloat (bulk, absorption, no float). |
| ReCharge Volts | Sets the recharging volts to tell the charger to initiate charging when the battery drains past the value setting. |
| Auto ReCharge | Enables or disables automatic charging. When there are two or more power sources for charging batteries, Auto ReCharge can be disabled to allow manual charging of batteries. |

Table 11 Charger Settings Menu Description

| Item | Description |
|--------------------------|---|
| Absorb Time | Sets the maximum time spent in the absorption stage, before transitioning to float or no float. NOTE: The Absorb Time setting resets to its default value of 180 minutes when the Battery Type is changed except when changing to Custom Settings. In Custom Settings, the Absorb Time setting will not reset to its default value. |
| Default Batt Temp | Selects the battery temperature charging compensation if a battery temperature sensor is not installed. In the absence of a battery temperature sensor, the charger uses one of three settings: Cold (5 °C/41 °F), Warm (25 °C/77 °F), or Hot (40 °C/104 °F). |

Battery Charger Functions

When AC power is available, the Freedom SW can operate as a battery charger. Different battery types and chemistries require different charging voltage levels. Not charging batteries at the required levels can shorten battery life or damage the batteries. The Freedom SW is configured at the factory to work with the battery types recommended for inverter applications. If the default settings do not work for your specific installation, you can adjust the charge stage settings (as recommended by the battery manufacturer) on the **Custom (Battery) Settings** menu (see page 63).

NOTE: This information is provided for guidance only. Variations in battery chemistry and site-specific environmental considerations mean that you should consult your system designer or battery manufacturer for specific recommendations for appropriate battery voltage and current settings.

Custom Battery Settings Menu

NOTICE

EQUIPMENT DAMAGE
 Consult your battery manufacturer and associated documentation before setting a custom battery type to avoid damaging your batteries during charging or equalization.

Failure to follow these instructions can damage the unit and/or damage other equipment.

Table 12 Setting Defaults and Ranges

| Model | Freedom SW 2012 / 3012 | | | Freedom SW 2024 / 3024 | | |
|--------------------------|------------------------|-------------------|-------|------------------------|-------------------|-------|
| | Default | Min | Max | Default | Min | Max |
| Eqiz Support | Enabled | Enabled, Disabled | | Enabled | Enabled, Disabled | |
| Eqiz Voltage | 15.5V | 13.5V | 16.0V | 31.0V | 27.0V | 32.0V |
| Bulk Voltage | 14.4V | 11.2V | 16.0V | 28.8V | 22.4V | 32.0V |
| Bulk Termination Voltage | 14.2V | 11.0V | 15.8V | 28.4V | 22.0V | 31.6V |
| Absorb Voltage | 14.4V | 12.0V | 16.0V | 28.8V | 24.0V | 32.0V |
| Float Voltage | 13.5V | 11.0V | 16.0V | 27.0V | 22.0V | 32.0V |
| Batt Temp Comp | 27-mV | 0-mV | 45-mV | 54-mV | 0-mV | 90-mV |

The **Custom Battery Settings** menu can be viewed if **Custom** is selected as the **Batt Type**. This menu allows you to adjust charging and equalization voltage for batteries with specifications that fall outside the default settings for the battery types the Freedom SW offers. You can also adjust the temperature compensation constant for the battery temperature sensor on this menu.

IMPORTANT: All settings for configuring a custom battery type are based on the default settings for a flooded battery type.

Appears only when Equalize support is Enabled.

| FSW3012 00: Cust Settings | |
|---------------------------|-----------|
| Eqiz Support | [Enabled] |
| Eqiz Voltage | [16.0V] |
| Bulk Voltage | [11.2V] |
| Bulk Termination Voltage | [11.0V] |
| Absorb Voltage | [13.5V] |
| Float Voltage | [-27mV/K] |
| BattTempComp | |

Follow procedures on "To select and change a configurable setting:" on page 43 to change the settings.

Figure 29 Custom Settings Menu Screen

Table 13 describes the items on the **Custom Battery Settings** menu.

Table 13 Custom Battery Settings Menu Description

| Item | Description |
|---------------------------------|--|
| Eq1z Support | Enables or disables the ability to enter an equalization cycle. Refer to the battery manufacturer's specifications to determine whether equalization is recommended. |
| Eq1z Voltage^a | Selects the equalization voltage. Consult your battery manufacturer for equalization voltage setting. |
| Bulk Voltage | Sets the bulk voltage for a custom battery type. This setting must be 0.4 V (or 0.2) or higher than Bulk Termination Voltage for the 24-volt model (or 12-volt model). See note below. |
| BulkTermination Voltage | Sets the bulk termination voltage for a custom battery type. This setting must be 0.4 V (or 0.2) or lesser than Bulk Voltage for the 24-volt model (or 12-volt model). See note below. |
| Absorb Voltage | Sets the absorption voltage for a custom battery type. |

Table 13 Custom Battery Settings Menu Description

| Item | Description |
|-----------------------|--|
| Float Voltage | Sets the float voltage for a custom battery type. See note below. |
| Batt Temp Comp | Battery temperature compensation for a custom battery type. This setting is the reference that the BTS uses to adjust the charging voltage when the temperature is above or below 25 °C (77 °F). |

a. The **Eq1z Voltage** setting is displayed when **Eq1z Support** is set to **On**.

NOTE: If a warning is received indicating that a setting is not accepted by the SCP, gradually increase the value of the setting until the SCP accepts it. This type of warning means that an internal minimum threshold value is being crossed and therefore the setting cannot be saved.

ACIn Settings

The **ACIn Settings** menu configures the voltage and frequency limits for AC Input quantification range. These are the limits at which the Freedom SW considers input voltage qualified—that is, suitable for charging batteries or powering loads. If the input voltage is not qualified according to these settings, the Freedom SW transfers from using AC input to inverting.

| FSM3012 00: ACIn Settings | |
|---------------------------|--------|
| ACIn Breaker | [30A] |
| ACIn Lo Volt | [95V] |
| ACIn Hi Volt | [135V] |
| ACIn Lo Freq | [55Hz] |
| ACIn Hi Freq | [65Hz] |

Follow procedures on "To select and change a configurable setting:" on page 43 to change the settings.

Figure 30 ACIn Settings Menu Screen

Table 14 Setting Defaults and Ranges

| Model | Freedom SW 2012 / 3012 | | | Freedom SW 2024 / 3024 | | |
|-------------|------------------------|------|------|------------------------|------|------|
| | Default | Min | Max | Default | Min | Max |
| AC1 Breaker | 30A | 5A | 30A | 30A | 5A | 30A |
| AC1 Lo Volt | 95V | 78V | 115V | 95V | 78V | 115V |
| AC1 Hi Volt | 135V | 125V | 140V | 135V | 125V | 140V |
| AC1 Lo Freq | 55Hz | 44Hz | 59Hz | 55Hz | 44Hz | 59Hz |
| AC1 Hi Freq | 65Hz | 61Hz | 70Hz | 65Hz | 61Hz | 70Hz |

Table 15 ACIn Settings Menu Description

| Item | Description |
|--------------------|--|
| AC1 Breaker | Sets the AC1 (Grid) breaker size, based on the size of the breaker installed on AC1. The installed breaker size must not exceed the capacity of the upstream distribution panel. The Freedom SW limits the maximum input current to this setting by derating its charging current to an equivalent of 80% of the AC breaker size. If the connected loads exceed the AC1 breaker setting, the AC breaker trips. |
| AC1 Lo Volt | Minimum acceptable input voltage level from the utility mains. NOTE: It is recommended to leave this setting to its default value and not to set it to the maximum allowed. Doing so might inadvertently derate charging power in jurisdictions where the nominal AC mains voltage or generator output is at 110 volts. |
| AC1 Hi Volt | Maximum acceptable input voltage level from the utility mains. |
| AC1 Lo Freq | Minimum acceptable utility mains input frequency. |

Table 15 ACIn Settings Menu Description

| Item | Description |
|--------------------|---|
| AC1 Hi Freq | Maximum acceptable utility mains input frequency. |

Gen Support

GEN Support is basically generator (and also shore power) support for the Freedom SW that allows power to be automatically drawn from the batteries to assist an AC generator or shore power to support heavy loads (for example, loads that exceed the available current from either a generator or shore power).

Generators and shore power have a limited output current and it is possible to reach this limit when operating heavy loads. When heavy current demand from the load is needed, additional power from the batteries can supply the needed energy.

In addition, the battery charger can reduce its charging current to the batteries so the combined charge AC current and total load current do not exceed the capacity of the generator (and shore power) or trip its output breakers or fuses.

| | |
|-------------------------|--------------------------------------|
| FSW3012 00: GEN Support | |
| GenSup Mode | [Disabled] [*Disabled] [Enabled] |
| GenSup Amps | [30A] |

Follow procedures on "To select and change a configurable setting:" on page 43 to change the settings.

Figure 31 GEN Support Menu Screen

NOTE: Running and start-up (peak) currents are limited to the maximum current limits of the inverter.

system to control when to turn on the generator. **GEN Support** with shore power, however, does not need the Xanbus AGS.

Table 16 GEN Support Menu Description and Values^a

| Setting | Description | Default | Range |
|--------------------|---|-----------------|--------------------------|
| GenSup Mode | Turns the generator or shore power support feature on and off. | Disabled | Disabled, Enabled |
| GenSup Amps | Sets the generator or shore power load level at which the Freedom SW supplies power from the batteries to support the generator or shore power. | 24A | 4A to 24A |

a. Applies to all Freedom SW models.

The Freedom SW supports the generator or shore power when the AC load current drawn from the generator or shore power exceeds the **GenSup Amps** setting for one to two seconds.

The system can enter this state if the battery voltage is above **Low Battery CutOut (LBCO)** plus 1 volt and **GEN Support** is enabled. **GEN Support** with a generator can only work when the Xanbus AGS is installed and detected in the

Stacking Configuration Menu

The **Stacking** menu configures the Freedom SW to operate as a part of a multi-unit installation.




Figure 32 Stacking Menu Screen

IMPORTANT: Accessing this menu automatically places the Freedom SW in standby mode. When entering the **Stacking** menu, the unit identifies itself by flashing all front panel LEDs. After exiting the **Stacking** menu, the Freedom SW returns to operating mode and the front panel LEDs stop flashing.

NOTE: The same **Battery** number and **AC In** number must be used for all stacked Freedom SW units.

When installing a stacked system, every setting on the **Stacking** menu (except for **Dev Name**) must be configured for each Freedom SW in the system. The settings should be configured in the following order:

- Dev Number
- Stack Mode

Table 17 Stacking Menu Description and Values^a

| Item | Description | Default | Range |
|-------------------|--|--|-----------------------------|
| Dev Name | Allows the customizing of the default name for the inverter/charger. This setting is optional and does not affect operation. See "Setting the Device Name" on page 71. | FSW3012 in the case of Freedom SW 3012. | Can be changed by the user. |
| Dev Number | Allows setting of a unique unit number in a two-unit system. See "Setting the Device Number" on page 72. | 00 | 00–31 |

Table 17 Stacking Menu Description and Values^a

| Item | Description | Default | Range |
|-------------------|---|----------------|--|
| Stack Mode | Series Stacking: For this to operate, one Freedom SW must be configured to Master and the other as L2Master , otherwise a system-wide fault is asserted. | Master | Master ,S lave, L2Master |
| | Parallel Stacking: For this to operate, one Freedom SW must be configured to Master and the other as Slave , otherwise a system-wide fault is asserted. | Master | Master ,S lave, L2Master |
| AC In | Identifies to the system the kind of AC input the inverters are accepting. | SHORE 1 | SHORE 1– SHORE5 GEN1– GEN5 NONE |
| Battery | Points the system to which battery bank is used. | Batt1 | Batt1– Batt5 |

a. Applies to all Freedom SW models.

Setting the Device Name

The **Dev Name** setting allows you to customize the name of the Freedom SW as it is displayed on other screens and menus.

Changing the device name is not mandatory for stacking to be successful. It simply allows a user to distinguish between two inverter/chargers that are installed in the same system.

The available characters are:

- A to Z
- a to z
- 0 to 9
- space

NOTE: Increasing the number of characters in a device name may cause other text on the same line to run off the edge of the screen. Device names should be limited to 10 characters or less.

Some examples of names are: “Master”, “Slave”, “Main”, and “Secondary”.

To customize the Freedom SW name:

1. On the device setup menu, select **Advanced Settings**. If **Basic Settings** appears instead of **Advanced Settings** on the device setup menu, display **Advanced Settings** by pressing **Enter** + Up arrow + Down arrow at the same time.
2. Select the **Stacking** menu.
3. Select **Dev Name**.
4. Press **Enter**.
The last letter of the Freedom SW name is highlighted.
5. Begin customizing the device name.
 - To change the character, press the up or down arrow button. Holding down the button causes the characters to scroll more quickly.
 - To delete the character, press **Func**.
 - To add characters, press **Enter**.
6. When the correct character is shown, press **Enter** to select it.
7. After pressing **Enter** to select the last character of your customized device name, press **Enter** again to return to the menu.

Setting the Device Number

Setting the device number gives a Xanbus-enabled device a unique identity when several devices of the same type are installed in the power system network. When each identical device has a unique number, the Xanbus SCP can correctly identify and display status information for each device. A device number consists of two digits ranging from 00 (default) to 31.

If only one of each type of device is installed in the network, you do not need to set the device number. However, setting the device number to a value other than 00 is recommended in case you need to use the **Restore Defaults** command (which resets the device number to 00). After performing the command, checking that the device number has returned to 00 indicates that the command was successfully completed.

To set the Freedom SW device number:

1. On the Freedom SW Setup menu, select **Advanced Settings**.

If **Basic Settings** appears instead of **Advanced Settings** on the **Setup** menu, display **Advanced Settings** by pressing **Enter** + Up arrow + Down arrow simultaneously.

On the **Advanced Settings** menu, select **Stacking** and press **Enter**.

2. On the **Stacking** menu, select **Dev Number**.
3. Press **Enter** to highlight the instance number.
4. Use the Up and Down arrow buttons to adjust the two-digit identifier number.
5. Press **Enter**.




Figure 33 Setting a Device Number





Cascading

The **Cascading** feature is found in the **System Settings** menu only when two inverters are configured as a stacked pair (see “Stacking Configuration Menu” on page 69). A stacked pair has one Master unit and one Slave unit. The cascading feature allows manually entered inverter/charger settings on the Master unit to be automatically cascaded (or copied) to the Slave unit when the two units are meant to have the same settings. Cascading helps simplify the duplication of settings of one inverter into another. The feature is **Enabled** by default but may be **Disabled** to accommodate different settings for the Master and Slave units. Review with a qualified system designer before adopting different settings for the Master and Slave units.

To change Cascading settings:

1. From the **System Status** screen, press the **Enter** button.
The **Select Device** menu screen appears.
2. From the **Select Device** screen, press the **Enter** button.
The **System Settings** menu screen appears.
3. From the **System Settings** screen, press the Down arrow button to highlight **Cascading**.

4. Press **Enter** and use the Up and Down arrow buttons to change selections.
5. Press **Enter** again to choose a selection.
6. Press **Func** (3x) to return to the **System Settings** menu.



Steps 4 to 6 are not shown.

Resetting the Freedom SW to Default Settings

The **Restore Defaults** command returns the Freedom SW to factory default settings. After using the **Restore Defaults** command, the Freedom SW is no longer configured for the power system.

To restore Freedom SW default settings:

1. On the **Adv Settings** menu, select **Restore Defaults**.

Warning **W252** appears, asking to confirm the command.

2. To cancel the command, press **Func**. To continue with the **Restore Defaults** command, press **Enter**.

IMPORTANT: If a warning is already active in the system, selecting **Restore Defaults** brings up the **Warnings** list, with warning **W252** at the top. Press **Enter** to view **W252** and continue with the restore defaults process.

NOTICE

EQUIPMENT DAMAGE

Do not restore defaults while the Freedom SW is operating. De-energize the power system and disconnect the Freedom SW AC input before restoring defaults. Reconfigure the Freedom SW before reconnecting the AC input and re-energizing the power system.

Failure to follow these instructions can damage the unit and/or damage other equipment.

Using the Advanced Features




Figure 34 Adv Features Menu Screen

Table 18 Adv Features Description and Values^a

| Item | Description | Default | Range |
|---------------|---|----------|-------------------|
| StoreInvState | When enabled remembers the state of the inverter function prior to a power down (that is, when AC and DC power sources are disconnected) or prior to a Standby (Power Save) mode. When the Freedom SW is powered up again or put back on Operating mode, the inverter function reverts back to its prior state. | Disabled | Disabled, Enabled |

a. Applies to all Freedom SW models.

To store the state of the inverter to memory:

1. Press and hold the **STBY/ON Fault Clear** button on the SCP for more than five seconds to switch to Standby (Power Save) mode.
2. Select **Advanced Settings** on the SCP. See “To select the Advanced Settings menu screen:” on page 54.
3. On the **Advanced Settings** menu, select **Adv Features**.
4. On the **Advanced Features** menu, select **StoreInvState**.
5. Press **Enter** and use the Up and Down arrow buttons to change the setting to **Enabled**.
6. Press **Enter** again to choose the selection.
7. Press **Func** until you return to the **System Status** screen.
8. Press and hold the **STBY/ON Fault Clear** button on the SCP for more than five seconds to switch back to Operating mode.

Battery Charging Reference

This section describes the multistage charging algorithm (formula) of the Freedom SW.

Battery Types

Freedom SW charges flooded (or wet) lead-acid, Gel, AGM (absorbed glass mat), and custom batteries.

- **Flooded (or wet)** batteries have removable battery caps for refilling with distilled water and testing the electrolyte.
- **Gel** batteries have the electrolyte in the form of a gel rather than a liquid and do not require topping up. Gel batteries are sealed and the battery caps are not removable.
- **AGM (Absorbed Glass Mat)** batteries are similar to gel batteries except that the electrolyte is absorbed into a fiberglass matting.
- **Custom** battery is configured by the dealer, factory, or service center for battery types other than those listed above.

NOTICE

RISK OF BATTERY DAMAGE

Do not mix battery types. The Freedom SW can only select one battery type setting for all batteries connected to its bank. All connected batteries should either be: Flooded (or wet) or Gel or AGM or Custom.

Failure to follow these instructions can damage the unit and/or damage other equipment.

Charge Algorithm Stages

Three-Stage charging

If three-stage charging is enabled, the Freedom SW will charge batteries in a sequence known as three-stage charging. Whenever qualified AC power is present at the inverter's input, it passes power through to the connected load and begins charging the batteries. The charging voltage delivered to the battery depends on the battery's:

- Type setting
- Temperature (by switch setting or battery temperature sensor)
- State of charge

The three automatic stages are:

- Bulk
- Absorption
- Float

See Figure 35 for a graph of the three-stage charging profile.

There is a fourth stage, equalization, which is initialized manually as it is only performed occasionally and only on flooded (or wet) batteries.

The charging cycle is a multistage (three-stage) process. Whenever qualified AC power is present at the inverter's input, it passes power through to the connected load and begins charging the batteries.




Figure 35 Three-Stage Battery Charging Cycle

NOTE:

When the charge cycle is interrupted, the charger will restart charging at the beginning of the multistage algorithm.

Exit Current Threshold can be effectively disabled by programming the amp-hour capacity to the minimum. In this case, absorption will only exit once the Max Absorption timer expires.

Charge current during equalize state (optional state not shown here) is normally limited to 10% of the programmed amp-hour capacity setting. If this setting is programmed to the maximum, the charge current during equalize is instead limited to whatever is programmed for the maximum current limit of the unit.

Synchronized charge states are active when more than one charging device is connected in the system via the Xanbus network.

- The first unit (Freedom SW) to enter bulk, causes all other chargers to enter bulk.
- The first Freedom SW to enter absorption causes all other Freedom SWs to enter absorption.
- The last Freedom SW ready to exit absorption triggers all Freedom SWs to exit absorption and exit charge.

Bulk Stage

Bulk charge is the first stage in the charging process and provides the batteries with a controlled, constant current. Once the battery voltage rises to the absorption voltage threshold, the charger switches to the absorption stage.

Table 19 Preset Bulk Voltage Settings

| Battery Type | Termination Voltage | | Preset Bulk Voltage | |
|--------------|----------------------|----------------------|----------------------|----------------------|
| | 12V models | 24V models | 12V models | 24V models |
| Flooded | 14.2 | 28.4 | 14.4 | 28.8 |
| Gel | 14.0 | 28.0 | 14.2 | 28.4 |
| AGM | 14.1 | 28.2 | 14.3 | 28.6 |
| Custom | 14.4 (changeable) | 28.8 (changeable) | 14.4 (changeable) | 28.8 (changeable) |

Absorption Stage

Absorption charge is the second stage of battery charging and provides the batteries with a controlled, constant voltage. During this stage, the current drawn by the batteries slowly decreases. When this current falls below 2% of the battery capacity, or when the configurable **Absorb Time** expires, the charger switches to the Float or NoFloat stage, depending on the selected charge cycle. The timer begins when the battery voltage is above the bulk termination voltage for three minutes.

Table 20 Preset Absorption Voltage Settings

| Battery Type | Preset Absorption Voltage | |
|--------------|---------------------------|----------------------|
| | 12V models | 24V models |
| Flooded | 14.4 | 28.8 |
| Gel | 14.2 | 28.4 |
| AGM | 14.3 | 28.6 |
| Custom | 14.4 (changeable) | 28.8 (changeable) |

The Freedom SW transitions to the float stage if either one of the following two conditions are met:

1. The charge current allowed by the batteries falls below the exit current threshold, which is equal to 2% of the programmed battery capacity (for a 500 amp-hour battery bank, this would be 10 amps), for three minutes.
2. The Freedom SW has been in absorption for the programmed maximum absorption time limit. The default is 3 hours, but the time limit is programmable from 1 minute to 8 hours.

NOTE: If there are DC loads on the batteries, the charger's current may never decrease to a level to initiate the next stage of charging. In this case, the charger would stay in absorption until the **Absorb Time** setting is reached.

NOTE: To make sure the charger does not remain in absorption for too long, adjust **Absorb Time** on the **Charger Settings** menu. The timer begins at the start of the absorption stage and terminates absorption charging if the charge current does not decrease to below 2 per cent of the battery capacity before the **Absorb Time** setting expires. The **Absorb Time** setting may be increased if the charge cycle continually runs the full **Absorb Time** in the absence of DC loads. This is an indication of too large a battery bank for the selected **Absorb Time** setting.

Float Stage

Float charge maintains the batteries slightly above the self discharge voltage of the batteries. The charge current in float is the current necessary to maintain the batteries at the **Float Voltage** setting, limited only by the inverter's capability or other settings that limit the inverter's maximum charge rate. Float charging reduces battery gassing, minimizes watering requirements (for flooded batteries), and makes sure the batteries are in a constant state of readiness. When three-stage charging is selected, the charger automatically switches to the float stage after the batteries have received a bulk and absorption charge (see Figure 35). The batteries are maintained at the default float voltage level for the selected battery type or the voltage selected under **Float Voltage** on the **Custom Battery Settings** menu.

Table 21 Preset Float Voltage Settings

| Battery Type | Preset Float Voltage | |
|--------------|----------------------|----------------------|
| | 12V models | 24V models |
| Custom | 13.5 (changeable) | 27.0 (changeable) |

NOTE: The battery voltage can increase above the float voltage when using an external charging device such as PV arrays, wind turbines, and micro-hydro generators. Be sure to include appropriate charge management equipment with all external DC sources.

Table 21 Preset Float Voltage Settings

| Battery Type | Preset Float Voltage | |
|--------------|----------------------|------------|
| | 12V models | 24V models |
| Flooded | 13.5 | 27.0 |
| Gel | 13.8 | 27.6 |
| AGM | 13.4 | 26.8 |

Two-Stage Charging Process

Two-stage (or no float) mode differs from an ordinary three-stage charge mode in that it does not continuously maintain the battery at float voltage. Instead, the Freedom SW begins charging the battery in bulk mode whenever the battery voltage drops below the recharge level. While the battery voltage is above the recharge level the inverter's AC transfer switch continues to pass power through from the utility grid to the loads, but does not actively charge the batteries.

Two-stage mode increases efficiency of utility connected systems by reducing the amount of power consumed by the inverter and batteries compared to when the battery is continuously maintained at **Float Voltage**. This feature can extend the life of most batteries.

NOTE: If the AC input fails or drops below the lower VAC limit (as set in AC Settings), the complete multistage charge cycle (bulk, absorption, float/no float) restarts once the source AC recovers to within the acceptable range. If the batteries are already nearly full, the charge cycle will take little time to complete.




Figure 36 Two-Stage Charging Cycle

NOTE:

When the charge cycle is interrupted, the charger will restart charging at the beginning of the multistage algorithm.

Exit Current Threshold can be effectively disabled by programming the amp-hour capacity to the minimum. In this case, absorption will only exit once the **Max Absorption** timer expires.

Charge current during equalize state (optional state not shown here) is normally limited to 10% of the programmed amp-hour capacity setting. If this setting is programmed to the maximum, the charge current during equalize is instead limited to whatever is programmed for the max current limit of the unit.

Synchronized charge states are active when more than one charging device is connected in the system via the Xanbus network.

- The first unit to enter bulk, causes all other chargers to enter bulk.
 - The first Freedom SW to enter absorption causes all other Freedom SWs to enter absorption.
 - The last Freedom SW ready to exit absorption triggers all Freedom SWs to exit absorption and exit charge.
-

Equalize Charging

Many battery manufacturers recommend periodic equalize charging to counter cell charge imbalance and capacity-robbing electrolyte stratification. Equalizing helps to improve battery performance and lifespan by encouraging more of the battery material to become active.

Battery equalization is a controlled overcharging method that mixes up stratified electrolyte and reactivates unused areas of the plate material. Periodic equalizing can help to regularly restore batteries to a full and healthy state of charge.

Consult the battery manufacturer's recommendation for equalize charging settings. Sealed batteries should **never** be equalized. Consult the battery manufacturer for optimal charging procedures when using sealed batteries.

When **Equalize** mode is enabled, the battery is charged from bulk to absorption, and then to the equalize phase. The Freedom SW will transition from the absorption phase to equalize if:

- the DC charge current is below 2% of the configured battery capacity (for example, 8.8A for 440Ah)
- the absorption time is exceeded (for example, 180 min)

After absorption, the maximum charge DC current is set to 10% of battery capacity (for example, 44A for 440Ah). See Figure 37. This constant current charge will continue until the voltage has increased to the equalize voltage at which point the battery will be regulated at the temperature-compensated equalize voltage.

If the battery capacity is set to zero (Ah=0 effectively disables the exit current criteria for the absorption charge stage making the absorption stage defined by time only), the equalize charge current is fixed at maximum 100% of the charge rate.

Equalization duration is fixed at one hour.

Table 22 Preset Equalization Voltage Settings

| Battery Type | Preset Equalization Voltage | |
|--------------|-----------------------------|----------------------|
| | 12V models | 24V models |
| Flooded | 16.0 | 32.0 |
| Gel | n/a | n/a |
| AGM | n/a | n/a |
| Custom | 16.0 (changeable) | 32.0 (changeable) |




Figure 37 Equalize Charging

Troubleshooting

General Troubleshooting Guidelines

This section will help you narrow down the source of any problem you may encounter. Please read the following troubleshooting steps:

1. Check for a warning or fault message on the Xanbus SCP or a fault code on the inverter information panel. If a message is displayed, record it immediately.
2. As soon as possible, record the conditions at the time the problem occurred. These details should include the following information:
 - Loads the Freedom SW was running or attempting to run
 - Battery condition at the time of failure (battery voltage or temperature, for example), if known
 - Recent sequence of events (for example, charging had just finished, utility grid had failed but the inverter did not come on)
 - Any known unusual AC input factors such as low voltage or unstable generator output
 - Extreme conditions which may have existed at the time (temperature or moisture, for example).
3. Attempt the solution indicated in these guidelines.
4. If your inverter information panel or Xanbus SCP is not displaying a Fault LED, check the following list to make sure that the present state of the installation allows proper operation of the unit. Read these guidelines carefully.
 - Is the Freedom SW located in a clean, dry, adequately ventilated area?
 - Have the AC input breakers opened? If so, your pass-through load may have exceeded the rating of one or more of the input breakers.
 - Are the battery cables adequately sized and short enough? See the Installation Guide for more information.
 - Is the battery in good condition and are all DC connections tight?
 - Are the AC input and output connections and wiring in good condition?
 - Are the configuration settings correct for your particular installation?
 - Are the display panel and the communications cable properly connected and undamaged?
 - Is the battery temperature sensor and its cable properly connected and undamaged?

5. Contact Customer Service for further assistance. Please be prepared to describe details of your system installation and provide the model and serial number of the unit. See the front and/or back of the manual for contact information.

Inverter Applications

The Freedom SW performs differently depending on the AC loads connected to it. If you are having problems with any of your loads, read this section.

Resistive Loads

Resistive loads are the easiest and most efficient to drive. Voltage and current are in phase, which means they are in step with one another. Resistive loads generate heat in order to accomplish their tasks. Toasters, coffee pots, and incandescent lights are typical resistive loads. It is usually impractical to run larger resistive loads—such as electric stoves and water heaters—from an inverter due to their high current requirements. Even though the inverter may be able to accommodate the load, the size of battery bank will limit inverter run time.

Motor Loads

Induction motors (AC motors without brushes) require up to six times their running current on startup. The most demanding are those that start under load (for example, compressors and pumps). Of the capacitor start motors (typical in drill presses and band saws, for example), the largest you can expect to run is one horsepower. Universal motors are generally easier to start. Check that the Locked Rotor Amps (LRA) rating of the motor load does not exceed the maximum surge current rating of the inverter. Since motor characteristics vary, only testing will determine whether a specific load can be started and how long it can be run.

If a motor fails to start within a few seconds or loses power after running for a time, it should be turned off. When the inverter attempts to start a load that is greater than it can handle, the inverter may shut down from an AC overload fault.

Problem Loads

Very Small Loads If the power consumed by a device is less than the threshold of the search mode circuitry, and search mode is enabled, the inverter will not run. Most likely the solution will be to disable **Search** mode or lower the sense threshold.

Fluorescent Lights and Power Supplies Some devices cannot be detected when scanned by search mode circuitry. Small fluorescent lights are the most common example. Some computers and sophisticated electronics have power supplies that do not present a load until line voltage is available. When this occurs, each unit waits for the other to begin. To drive these loads, either a small companion load like a light bulb rated for more than the **Search Watts** setting must be used to bring the inverter out of search mode, or the inverter may be programmed to remain on by disabling **Search** mode. (See “Using Search Mode” on page 45.)

Clocks You may notice that your clocks are not accurate. Some of the clocks on your appliances may reset when the Freedom SW is in search mode.

Searching When the inverter is in search mode, it may fail to start some loads even though the rated wattage on the load is more than the **Search Watts** setting. Disable **Search** or apply an additional load (companion load) to make the inverter exit search mode.

Troubleshooting the Freedom SW via the SCP

The Freedom SW is designed with a number of protection features to provide efficient operation. If, however, you have any problems operating your inverter/charger read this troubleshooting chapter.

If you cannot resolve the problem, record the information about your system. This information will help your dealer or customer service to assist you better when you contact them.

DANGER

ELECTRICAL SHOCK HAZARD

Do not disassemble the inverter/charger. The Freedom SW contains no user-serviceable parts.

Failure to follow these instructions will result in death or serious injury.

When a detected fault or warning message appears, you can acknowledge the message to clear the screen. To acknowledge a fault or warning message, press the **Enter** button on the SCP. This action does not clear the fault or warning condition, so you should consult “Detected Fault Messages” on page 93 and “Detected Warning Messages” on page 102 for suggested actions after you have acknowledged

the message. Refer to the *Xanbus System Control Panel Owner’s Guide* for more information on detected faults and warnings.

Detected Fault Types

There are three types of detected fault messages: automatic faults, manual faults, and escalating automatic faults. Table 1 describes how they differ in their behavior and how you can respond to them when they appear on the SCP.

Table 1 Detected Fault Types and Behaviors

| Fault type | Behavior |
|-------------------|---|
| Automatic fault | Clears automatically if the detected condition that generated the message goes away. You can also acknowledge automatic faults without waiting for them to clear automatically. |

Table 1 Detected Fault Types and Behaviors

| Fault type | Behavior |
|-----------------------------|---|
| Manual fault | <p>Requires you to clear it by:</p> <ul style="list-style-type: none"> • Selecting Clear Faults on the Freedom SW or on the device that generated the detected fault (if the condition still exists, the fault message reappears). • Correcting the condition that detected the fault. |
| Escalating automatic faults | <p>Clears automatically if the detected fault condition goes away, just like an automatic fault.</p> <p>However, if an escalating automatic fault occurs several times within a defined time period, the escalating automatic fault becomes a manual fault, requiring user intervention. For example, if three detected faults occur in one minute, it will no longer clear itself but becomes a manual fault. Then, you must identify the problem, correct the condition that detected the fault, and clear the fault or reset the device.</p> |

To view a fault list:

1. On the Select Device menu, highlight System and press **Enter**.
2. On the System Settings menu, highlight View Fault List.
3. Press **Enter**.

Detected Warning Types

There are two types of detected warnings: automatic and manual. When the Freedom SW detects a warning condition, it displays a warning message on the SCP.

Table 2 describes how they differ in their behavior and in how you can respond to them when they appear on the SCP.

To view a warning list:

1. On the Select Device menu, highlight System and press **Enter**.
2. On the System Settings menu, highlight View Warning List.
3. Press **Enter**.

Table 2 Detected Warning Types and Behavior

| Warning type | Behavior |
|-------------------|---|
| Automatic warning | Clears automatically if the detected condition that generated the message goes away. You can also acknowledge automatic warnings without waiting for them to clear automatically. |
| Manual warning | Requires you to acknowledge it before you can proceed with configuring or operating the Freedom SW. Manual warnings are usually in the form of a Yes/No question that you may acknowledge by pressing the Enter button on the SCP for Yes and the Func button for No. Refer to the <i>Xanbus System Control Panel Owner's Guide</i> for more information. |

Table 3 provides a detailed description of the detected fault messages and solutions. If you are unable to resolve the problem after referring to this table, contact your dealer or Customer Service.

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|---------------------|--------------------------------|---|--------------------------------------|---|
| F1 | AC Output under voltage | Escalating Auto Fault. Must occur 3 times in 30 seconds before becoming a manual fault. | Inverter voltage is under 100 volts. | Remove excessive load. |
| F2 | AC Output over voltage | Escalating Auto Fault. Must occur 3 times in 30 seconds before becoming a manual fault. | Inverter voltage is over 135 volts. | Check if there is an external power source that is running parallel to the inverter's output. |
| F17 | Relays Welded | Manual | AC backfeed from welded relay. | Service required. |
| F18 | | | | |

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|---------------------|---------------------------------|-------------------|--|---|
| F44 | Battery Over Temperature | Automatic | Battery temperature is over 140 °F (60 °C). Poor battery compartment ventilation. | Stop charging if necessary. Check cable connections. Check battery voltage/current and temperature. If battery is not accepting charge, it may need to be replaced. Check for excessive ambient temperature and adequate ventilation in the battery compartment. |
| | | Automatic | BTS may be damaged. | If the unit displays a temperature of over 212 °F (100 °C), the BTS will need to be replaced. |
| F46 | Controller Error | Manual | Unit's control board may be damaged. | Service is required. |

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|---------------------|-------------------------------------|-------------------|---|---|
| F47 | DC Under Voltage (Immediate) | Automatic | Immediate battery under voltage fault. | Check battery condition (short or open cells) and ensure correct voltage. Battery state charge or capacity is so low that the DC voltage collapses when inverter load is applied. Inverter load is so large that the DC voltage collapses when inverter load is applied. |
| F48 | DC Under Voltage (Fault) | Automatic | Voltage at the DC input terminals is below the Low Battery Cut Out (LBCO) setting for 10 seconds. | Check for the correct battery voltage at the inverter's DC input terminals. Check for external DC loads on the batteries. Check condition of batteries and recharge if necessary. Reduce the Low Battery Cut Out (LBCO) setting. Battery bank capacity may be inadequate for the loads in the system. |

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|---------------------|------------------------|-------------------|---|--|
| F49 | DC Over Voltage | Automatic | Voltage at the DC input terminals is above the High Battery Cut Out Setting | Clear the fault and attempt restart. Ensure battery voltage is 10–16 VDC at Freedom SW terminals. Check all other charging source outputs, battery cables. |
| F52-F56 | EEPROM ERROR | Manual | A problem has been detected with the internal memory. | Clear the fault and check the latest configuration made or any recent configurations. If fault detection reoccurs or occurs frequently, service is required. |

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|---------------------|------------------------------|-------------------|---|---|
| F57 | FET1 Over Temperature | Automatic | Ambient temperature may be too high. | Ensure adequate ventilation around the Freedom SW. Allow inverter to cool down and try restarting. |
| | | | Operating too large of a load for too long while inverting. | Remove excessive inverter loads. |
| | | | Inverter cooling fan may have failed. | If the temperature is above 104 °F (40 °C), the fan should be on. Hold your hand or a piece of paper to the inverter vent to check if the fan is working. Both fans should be active at the same time. |
| | | | Inverter airflow intake may be blocked. | Increase the clearance around the inverter and/or unplug the airflow intake vents. |
| F58 | FET2 Over Temperature | Automatic | Same as F57 . | Same as F57 . |

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|---------------------|-------------------------------------|--|--|---|
| F59 | G0CFG process failed | Manual | The unit may be running outdated firmware. | Clear the fault and check if the latest firmware is installed. If not, download and install the latest firmware from the website. |
| F62 | Invalid Interrupt | Manual | Unit's control board may be damaged. | Service is required. |
| F63 | Power Board Temp unreadable | Automatic | Temperature sensor is damaged. | Service required. |
| F64 | AC overload | Escalating Auto Fault. Must occur 3 times in 60 seconds before becoming a manual fault. | Persistent excessive inverter current above rated current. | Avoid loads with long surge current. |
| F67 | Watchdog Error | Manual | Unit's control board may be damaged. | Service is required. |
| F68 | Transformer Over Temperature | Automatic | Same as F57. | Same as F57. |

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|---------------------|------------------------------------|-------------------|---|---|
| F69 | External Sync Failed | Automatic | When Series stacking—the Stacking cable is not installed. | Install the Stacking cable to connect the two inverter/chargers. |
| F70 | Unique Dev# Needed | Automatic | When stacking (Series or Parallel)—if two units have the same Device Number. | Change the Device Number of one unit. See “Setting the Device Number” on page 72. |
| F71 | Too Many Masters | Automatic | When stacking (Series or Parallel)—if two units are configured as Master units. | Change one unit to a Slave unit. See Stack Mode under “Stacking Configuration Menu” on page 69 in Table 17. |
| F73 | Transformer Temp unreadable | Automatic | Temperature sensor is damaged. | Service required. |

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|--------------|--------------------------------|------------|--|--|
| F74 | Other Unit Invert Fault | Automatic | When stacking (Series or Parallel)—if one of the units encounters a fault that needs to be resolved. | Clear the primary fault on the unit that caused this fault. |
| F75 | Master Inverter Lost | Automatic | When Parallel stacking—if the Slave unit cannot detect the Master unit in the Xanbus network. | Make sure that the two units are connected in the same Xanbus network. Check cable connections and ensure that the plugs are neatly inserted in the ports. Check if the Xanbus network is properly installed with network terminators. |
| F76 F77 | No Masters | Automatic | When stacking (Series or Parallel)—if all units are configured as Slave. | Assign the other unit as Master. |
| F79 | Battery Sensor Short | Automatic | The BTS has been damaged. | Replace the BTS. |

Table 3 Detected Fault Messages

| Fault Number | Message | Fault Type | Cause | Solution |
|---------------------|------------------------------------|-------------------|---|--|
| F85 | PowerBoard Over Temperature | Automatic | Same as F57. | Same as F57. |
| F86 | Dead Battery Detected | Automatic | When battery voltage is below the allowable charging voltage. | Recharge the battery with an external charging device. If the error persists, then the battery may be defective. Replace the battery. |
| F88 | MPPT Ground Fault | Automatic | In a Xanbus network, an MPPT has detected a ground fault (MPPT generated code F56). | Check the MPPT and correct the ground fault. |

Table 4 provides a detailed description of the detected warning messages and solutions. If you are unable to resolve the problem after referring to this table, contact your dealer or Customer Service.

Table 4 Detected Warning Messages

| Fault Number | Message | Cause | Solution |
|---------------------|-----------------------------------|---|---|
| W48 | DC under voltage (Warning) | Voltage at the DC input terminals is below the Low Battery Cut Out (LBCO) setting. | Check for the correct battery voltage at the inverter's DC input terminals. Check for external DC loads on the batteries. Check condition of batteries and recharge if necessary. Reduce the Low Battery Cut Out (LBCO) setting. Battery bank capacity may be inadequate for the loads in the system. |
| W72 | AC Out Assoc Mismatched | In a stacking configuration—the AC In settings are not the same for both units. | Change the AC In setting of both units in the stacking configuration to be the same. See “Stacking Configuration Menu” on page 69. |
| W87 | Inconsistent Frequencies | In a stacking configuration—the AC input low and high frequency settings are not the same for both units. | Change the AC input low and hi frequency settings of both units in the stacking configuration to be the same. See “ACIn Settings” on page 65. |

Table 4 Detected Warning Messages

| Fault Number | Message | Cause | Solution |
|--------------|-------------------------------|-------|----------|
| W92 | Input Connected to 3-Phase AC | | |

Specifications

NOTE: Specifications are subject to change without prior notice.

| Physical Specifications | Freedom SW 2012 | Freedom SW 2024 | Freedom SW 3012 | Freedom SW 3024 |
|-------------------------|--------------------------------------|-----------------|--------------------|-----------------|
| L × W × H | 387×343×197 mm (15.25×13.5×7.75 in.) | | | |
| Net Weight | 27.5 kg (60.5 lbs) | | 31.5 kg (69.4 lbs) | |

| Environmental Specifications | Freedom SW 2012 | Freedom SW 2024 | Freedom SW 3012 | Freedom SW 3024 |
|---|--|---|---|---|
| Nominal Ambient temperature | 30 °C (86 °F) | | 40 °C (104 °F) | |
| Invert mode: | | | | |
| <ul style="list-style-type: none"> Operating range (full power) Load @ maximum ambient | -20 to 30 °C (-4 to 86 °F) 1700W @ 60 °C | | -20 to 40 °C (-4 to 104 °F) 2600W @ 60 °C | |
| Charge mode: | | | | |
| <ul style="list-style-type: none"> Operating range (full power) Current @ maximum ambient | -4 to 104 °F (-20 to 40 °C) 80 A @ 140 °F (60 °C) | -4 to 104 °F (-20 to 40 °C) 40 A @ 140 °F (60 °C) | -4 to 77 °F (-20 to 25 °C) 120 A @ 140 °F (60 °C) | -4 to 104 °F (-20 to 40 °C) 60 A @ 140 °F (60 °C) |
| Storage temperature range | -40 to 185 °F (-40 to 85 °C) | | -40 to 185 °F (-40 to 85 °C) | |
| Humidity: Operation/Storage | ≤ 95% RH, non-condensing | | | |
| Altitude: | | | | |
| <ul style="list-style-type: none"> Operating Non-operating | 4,572 m (15,000 feet) 15,240 m (50,000 feet) | | | |
| Mounting | deck mount, wall mount with fans and DC/AC sides facing sideward | | | |

Specifications

NOTE: All inverter specifications are at nominal conditions: 12 (or 24) volts DC inverting 120 volts AC, unless otherwise specified.

| Inverter Specifications | Freedom SW 2012 | Freedom SW 2024 | Freedom SW 3012 | Freedom SW 3024 |
|---------------------------------------|---------------------------------|---------------------|--|---------------------|
| Output wave form | pure sine wave (true sine wave) | | | |
| Output power (continuous) | 2000 W (up to 30 °C) | | 3000 W (up to 40 °C) | |
| Output power (5 seconds) | 4000 W | | 6000 W | |
| Output current | 17 A | | 24 A | |
| Peak output current | 55 A | | 80 A | |
| Output frequency | 60 Hz ± 0.2 Hz | | 60 Hz ± 0.2 Hz | |
| Output voltage | 120 VAC | | 120 VAC | |
| AC output connection/s | Single | | Split phase in/dual out, Dual in/dual out | |
| Peak efficiency | 90% | 94% | 90% | 94% |
| No-load current draw (Inverter On) | <3 ADC | <1.5 ADC | <3 ADC | <1.5 ADC |
| Standby current draw (Inverter Off) | <0.25 ADC | <0.15 ADC | <0.25 ADC | <0.15 ADC |
| Input DC voltage range | 10–16 VDC | 20–32 VDC | 10–16 VDC | 20–32 VDC |
| Low battery voltage shutdown cut-off | 10.5 V (selectable) | 21.0 V (selectable) | 10.5 V (selectable) | 21.0 V (selectable) |
| High battery voltage shutdown cut-off | 16.5 V (selectable) | 33.0 V (selectable) | 16.5 V (selectable) | 33.0 V (selectable) |

NOTE: All charging specifications are at nominal conditions: ambient temperature of 77 °F (25 °C), 120 VAC, 60 Hz input, unless otherwise specified.

| Charger Specifications | Freedom SW 2012 | Freedom SW 2024 | Freedom SW 3012 | Freedom SW 3024 |
|--|---|-----------------|---|-----------------|
| Charging method | Three-stage charge (Bulk, Absorption, Float) Two-stage charge (Bulk, Absorption) The default charging method is three-stage. | | | |
| Without a battery temperature sensor | Three settings with the following temperature values: Cool 50 °F (10 °C), Warm 77 °F (25 °C), Hot 104 °F (40 °C) The default setting is Warm and it can only be changed by the factory, a dealer, or a service centre. | | | |
| With a battery temperature sensor (included) | The temperature compensation coefficients on a 12-volt battery are as follows: Flooded: $27 \text{ mV} \times (25 \text{ °C} - \text{BTS } \text{°C})$ Gel: $27 \text{ mV} \times (25 \text{ °C} - \text{BTS } \text{°C})$ AGM: $21 \text{ mV} \times (25 \text{ °C} - \text{BTS } \text{°C})$ | | The temperature compensation coefficients on a 24-volt battery are as follows: Flooded: $54 \text{ mV} \times (25 \text{ °C} - \text{BTS } \text{°C})$ Gel: $54 \text{ mV} \times (25 \text{ °C} - \text{BTS } \text{°C})$ AGM: $42 \text{ mV} \times (25 \text{ °C} - \text{BTS } \text{°C})$ | |
| Output current (maximum) | 100 ADC | 50 ADC | 150 ADC | 75 ADC |
| Output voltage | 12 VDC | 24 VDC | 12 VDC | 24 VDC |
| Output voltage range | 5–16 VDC | 12–32 VDC | 5–16 VDC | 12–32 VDC |
| Equalization cycle | Automatic, Manual by Xanbus SCP | | Automatic, Manual by Xanbus SCP | |
| Optimal charging efficiency | > 85% | | > 85% | |
| AC input power factor (at full charge rate) | > 0.98 | | > 0.95 | |
| AC input current | 24A max. (including pass-thru) | | 24A max. (including pass-thru) | |
| AC input voltage | 120 VAC | | 120 VAC | |
| AC input voltage range | 85–140 VAC | | 85–140 VAC | |
| Dead battery charge voltage | > 5 VDC | > 12 VDC | > 5 VDC | > 12 VDC |
| Supported AC input types | Single input (up to 30 amps) | | Split phase (up to 30 amps per line) Dual input (up to 30 amps per line) | |

Specifications

NOTE: All transfer specifications are at nominal conditions: ambient temperature of 77 °F (25 °C), 120 VAC, 60 Hz input, unless otherwise specified.

| Transfer and General Specifications | All Models |
|--|-------------------------------------|
| Transfer time—utility to invert | < 20 ms |
| Minimum AC input voltage for transfer | 85 VAC |
| Maximum AC input voltage for transfer | 135 VAC |
| Minimum AC input frequency for transfer | 45 Hz |
| Maximum AC input frequency for transfer | 70 Hz |
| Cooling | Fan-cooled, temperature controlled. |

| Regulatory Approvals | All Models |
|-----------------------------|--|
| Safety | CSA 107.1, UL 458 5th Ed. with marine supplement, ABYC E11 - Alternating Current and Direct Current Electrical Systems on Boats, and ABYC A31 - Battery Chargers and Inverters. |
| EMC | FCC Part 15, Class B Industry Canada ICES-003, Class B |

xantrex™
A MISSION CRITICAL ELECTRONICS BRAND

+1 800 670 0707
+1 408 987 6030
www.xantrex.com

97-0019-01-01 Rev H

Printed in China