# WeatherDeck® Toggle Switches

For use in WeatherDeck Waterproof Panels





- Manufactured for use in WeatherDeck Waterproof Panels (p. 111)
- Nickel-plated brass and phenolic non-corrosive construction

	4150-4154	4155
Amperage Max. Operating	10A @ 250V AC	-
	15A @ 125V AC	-
	15A @ 12V DC	5A @ 30V DC
Voltage Max. Operating	250V AC	30V DC
Terminal Size	0.25 in (6.35 mm)	0.25 in (6.35 mm)
Terminal Type	Quick Connect Tab	Quick Connect Tab

PN	Pole/Throw	Action ( ) = Momentary
4150	SPST	OFF-ON
4151	SPST	OFF-(ON)
4152	SPDT	ON-OFF-ON
4153	SPDT	(ON)-OFF-ON
4154	SPDT	(ON)-OFF-(ON)
4155	DPDT	ON-OFF-ON

### WeatherDeck® Toggle Switch Boot

Replaces boot on WeatherDeck Waterproof Panels



- For mounting on WeatherDeck Toggle Switches above
- UV resistant material resists discoloration and cracking
- Rated IP67 protected against immersion up to 1 meter for 30 minutes (See inside back cover)

Thread Material Nickel Plated Brass
Thread 15/32"-32UNS-2A

PN Description
4138 WeatherDeck Toggle Switch Boot

#### **Related Products**



WeatherDeck Panel

### **Panel Switches**

Mounts in an A-Series toggle circuit breaker aperture to provide multiple throw and switch configurations when circuit protection is provided elsewhere





Duck Button

 Ideal for generator starters, bilge pumps, horns, wipers, engine controls and other applications that require switching action other than ON-OFF or different pole configuration separate from circuit protection

- For use with A-Series Toggle Circuit Breaker Mounting Panel (p. 78)
- Supplied with mounting adapter for standard 5/8" circuit breaker mounting hole
- Nickel-plated brass and phenolic non-corrosive construction

	roggie	Push Button
Amperage Max. Operating	10A @ 250V AC	3A @ 250V AC
	15A @ 125V AC	6A @ 125V AC
	15A @ 32V DC	6A @ 32V DC
Terminal Size	0.25 in (6.35 mm)	0.25 in (6.35 mm)
Terminal Type	Quick Connect Tab	Quick Connect Tab
Actuator Color	White	White

PN	Actuator	Pole/Throw	Action ( ) = Momentary
8200	Push Button	SPST	OFF-(ON)
8204	Toggle	SPST	OFF-ON
8205	Toggle	SPST	OFF-(ON)
8206	Toggle	SPDT	ON-OFF-ON
8207	Toggle	SPDT	(ON)-OFF-ON
8208	Toggle	SPDT	(ON)-OFF-(ON)
8209	Toggle	DPST*	OFF-ON-(ON) / OFF-OFF-(ON)
8210	Toggle	DPST	OFF-ON
8211	Toggle	DPDT	ON-OFF-ON
8212	Toggle	DPDT	(ON)-OFF-ON

<sup>\*</sup> Progressive two circuit switch - maintains Circuit 1 while momentarily switching Circuit 2

# **360 Panel Adapters and Plugs**

Adapters allow mounting alternative switches and circuit breakers in the flat rocker aperture. Plugs fill empty flat rocker apertures.



PN	Description
4111	Adapts Push Button Reset-Only Circuit Breaker (p. 72)
4112	Adapts A-Series Toggle Circuit Breaker (p. 78) and Panel Switch
4119	Adapts 360 Panel Rocker Switch (p. 90)
4116	Panel Plug fills flat rocker circuit breaker aperture
4117	Panel Plug fills 360 Panel Rocker Switch aperture
8037	Panel Plugs fill Toggle Circuit Breaker aperture (6 pack)